



# AquaCal® Installation Manual









#### **Important**

1
Read this document before operating / installing this product
For additional product manuals and operation / installation procedures, please visit www.AquaCal.com
L

# Table of Contents

Contacting AquaCal AutoPilot, Inc.	1
Safety Instructions	1
1 - Installation	3
1.1 Positioning Equipment	4
1.2 Clearances	5
1.3 Dimensions	6
1.4 Plumbing	7
1.4.a Plumbing Requirements	7
1.4.b Plumbing Diagrams	7
1.4.c Water Connections to Heat Pump	10
1.4.d In-Line Chlorine Feeders	11
1.4.e Water Flow Rates	
1.4.f Adjusting Water Flow Using ΔT (Delta-T)	12
1.4.g Maintaining Ability to Winterize	
1.4.h Adjusting Water Pressure Switch	
1.5 Electrical	
1.5.a Electrical Requirements	
1.5.b Incoming Power Access Holes	19
1.5.c Access Panels	
1.5.d Verifying Transformer Setting	
1.5.e Three-Phase Adjustment	
1.5.f Schematic Location	
1.6 External Equipment	
1.6.a Connecting a Call Flex	
1.6.b Connecting a Chlorinator	
1.6.c Connecting External Controllers to Heat Pump	
c.1 Connecting Smart Bus Controllers	
c.2 Connecting Two-wire Controllers (with internal thermostat)	
1.6.d Connecting Gas Backup Heater to Heat Pump	
1.6.e Connecting Multiple Heat Pumps (Primary / Secondary)	
1.6.f Connecting a Pool/Spa Switching Relay	
1.7 Program Heat Pump for the Customer	
1.7.a Setting Date and Time	
1.7.b Setting Time and Date Format	
1.7.c Selecting Celsius or Fahrenheit	
1.7.d Configure Variable Speed Compressors	
1.7.e Setting Entry Code Option	
1.7.f Using Entry Code to Access Heat Pump	
1.7.g Resetting Factory Defaults	
1.8 Cleaning Equipment After Installation	
2 - Troubleshooting	
2.1 Fault Codes	
2.2 Issues and Resolutions	
3 - Appendix	
3.1 Factory Defaults	
3.2 Identifying Model Specifications	79

3.3 Weights	81
3.4 Heating Recommendations	82
3.5 Cooling Recommendations	
3.6 Available Accessories	82

## Contacting AquaCal AutoPilot, Inc.

## For further assistance, please contact the distributor or installer of this product.

If unavailable, please contact AquaCal® for a partner in your area. To better assist you, please have the heat pump model and serial number available.


• See "Identifying Model Specifications" on page 79.

Product Information:	
Website	www.AquaCal.com
Phone	(1) 727-823-5642
Hours	8-5 pm, Eastern M-F

Service Information:	
Website www.AquaCal.com/request-heat-pump-service/	

## **SAFETY INSTRUCTIONS**

- For personal safety, and to avoid damage to equipment, follow all safety instructions displayed on the equipment and within this manual. Repair and service of heat pump must be performed by an authorized service center.
- Warranties may be voided if the equipment has been improperly installed, maintained or serviced.
- If service is deemed necessary, please contact AquaCal. See "Contacting AquaCal AutoPilot, Inc." above.



When installing and using your heat pump basic safety precautions must always be followed, including the following:



Failure to heed the following will result in injury or death.

- The heat pump utilizes high voltage and rotating equipment. Use caution when servicing.
- RISK OF ELECTRICAL SHOCK FROM ENERGY STORED IN CAPACITORS MODELS EQUIPPED WITH VARIABLE FREQUENCY COMPRESSOR DRIVES STORE ELECTRICITY EVEN AFTER THE POWER HAS BEEN DEACTIVATED AT THE POWER BREAKER. Wait for 2 minutes after the shut down of equipment before servicing.
- Follow all National Electric Codes (NEC) and/or State and Local guidelines.



Failure to heed the following may result in injury or death.

- Installation and repairs must be performed by a qualified technician.
- The heat pump contains refrigerant under pressure. Repairs to the refrigerant circuit must not be attempted by untrained and/or unqualified individuals. Service must be performed only by qualified HVAC technicians. Recover refrigerant before opening the system.
- Improper water chemistry can present a serious health hazard. To avoid possible hazards, maintain pool/spa water per standards as detailed in the product's operation manual.
- Prolonged immersion in water warmer than normal body temperature may cause a condition known as Hyperthermia. The symptoms of Hyperthermia include unawareness of impending hazard, failure to perceive heat, failure to recognize the need to exit the pool or spa, and unconsciousness. The use of alcohol, drugs, or medication can greatly increase the risk of fatal Hyperthermia. People having an adverse medical history, or pregnant women should consult a physician before using a hot tub or spa. Children and the elderly should be supervised by a responsible adult.
- Prolonged immersion in water colder than normal body temperature may cause a condition known as Hypothermia. The symptoms of Hypothermia include shivering (although as hypothermia worsens, shivering stops), clumsiness or lack of coordination, slurred speech or mumbling, confusion and poor decision-making, drowsiness or low energy, lack of concern about personal welfare, progressive loss of consciousness, weak pulse and slow or shallow breathing. Persons having an adverse medical history, or pregnant women, should consult a physician before immersing in a cold body of water. Children and the elderly should be supervised by a responsible adult.
- This appliance is not to be used by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- Children must be supervised and are not to play with the appliance.

## NOTICE

Failure to heed the following may result in damage to equipment.

- Maintain proper water chemistry to avoid damage to the pump, filter, pool shell, etc.
- Water flow exceeding the maximum flow rate requires a bypass. Damage due to excessive water flow will void the warranty.

#### **SAVE THESE INSTRUCTIONS**

## 1 - Installation



Failure to heed the following may result in injury or death.

- Installation of this equipment by anyone other than a qualified installer can result in a safety hazard.
- The information contained throughout the "Installation" section is intended for use by qualified installation technicians familiar with the swimming Pool/Spa safety standards.

## **NOTICE**

Failure to heed the following may result in damage to equipment.

• Failure to protect equipment against corrosive conditions will adversely affect the life of the equipment and will void equipment warranty.

IN THIS SECTION:	
1.1 Positioning Equipment	4
1.2 Clearances	5
1.3 Dimensions	6
1.4 Plumbing	<b>7</b>
1.4.a Plumbing Requirements	7
1.4.b Plumbing Diagrams	7
1.4.c Water Connections to Heat Pump	10
1.4.d In-Line Chlorine Feeders	11
1.4.e Water Flow Rates	11
1.4.f Adjusting Water Flow Using ΔT (Delta-T)	12
1.4.g Maintaining Ability to Winterize	14
1.4.h Adjusting Water Pressure Switch	15
1.5 Electrical	16
1.5.a Electrical Requirements	16
1.5.b Incoming Power Access Holes	19
1.5.c Access Panels	20
1.5.d Verifying Transformer Setting	21
1.5.e Three-Phase Adjustment	22
1.5.f Schematic Location	22
1.6 External Equipment	23
1.6.a Connecting a Call Flex	23
1.6.b Connecting a Chlorinator	25
1.6.c Connecting External Controllers to Heat Pump	26
1.6.d Connecting Gas Backup Heater to Heat Pump	33
1.6.e Connecting Multiple Heat Pumps (Primary / Secondary)	
1.6.f Connecting a Pool/Spa Switching Relay	44
1.7 Program Heat Pump for the Customer	
1.7.a Setting Date and Time	47
1.7.b Setting Time and Date Format	
1.7.c Selecting Celsius or Fahrenheit	
1.7.d Configure Variable Speed Compressors	
1.7.e Setting Entry Code Option	
1.7.f Using Entry Code to Access Heat Pump	
1.7.g Resetting Factory Defaults	
1.8 Cleaning Equipment After Installation	62

## 1.1 Positioning Equipment

## **NOTICE**

Failure to heed the following may result in damage to equipment.

• Do not install equipment inside of a building.

#### **Outdoor Use Only**

## Do not install equipment inside of a room or building.

- Heat Pumps require unobstructed airflow for proper operation. Heat Pumps should never be installed indoors or in a location where airflow is restricted.
- If an indoor installation is being considered, the installer and dealer are strongly urged to contact the AquaCal Application Department, or a local Professional Engineer prior to proceeding.
- See "Clearances" on the facing page.

## Controlling Irrigation and Rainwater Runoff

- Irrigation water may damage heat pump components. Direct irrigation water away from the heat pump.
- The heat pump will withstand normal rainfall. Do not allow a roof slope to direct rainwater onto the heat pump. Have a gutter installed on the roof edge to direct this water away from the heat pump. Or install the heat pump in another location.

## Planning for Condensation

The heat pump can produce a large amount of condensation. The amount of water depends on air temperature and humidity.

- Install the heat pump with enough height to allow for water drainage.
- Plan for water drainage as needed.
  - See "Condensation Drain Kit (# STK0202)" on page 82.

#### **Mounting Pad Requirements**


- The heat pump's base must be installed on a flat and level surface that completely supports the entire base.
- Build the heat pump pad out of concrete or other code-approved material.
- Confirm the pad can support the weight of the heat pump. See "Weights" on page 81.
- Elevate the pad enough to allow for drainage.
- Make sure the pad is flat and level.
- Have the pad support the entire heat pump base in all directions.
- Do not install the heat pump on soil or grass.
- Do not allow the heat pump base to touch the building's foundation.
- Do not place the heat pump directly on a concrete floor. This can cause noise to be transmitted to an occupied space. If necessary install vibration dampers between the heat pump base and floor.
- Equipment pad must meet all requirements of authorities having code-related jurisdiction.


#### Anchoring to Pad

- Follow all applicable local, state, and national requirements regarding wind load anchoring.
- The shipping brackets used to secure the heat pump to the pallet are approved mounting (hurricane) brackets. They should be used to anchor the heat pump to the pad.
- If needed, contact AquaCal\* to obtain anchoring kit information. Please have the heat pump model number and serial number when requesting support. See "*Identifying Model Specifications*" on page 79.


## 1.2 Clearances

- Proper air circulation is required for the heat pump to operate efficiently. The following diagrams show the minimum clearances required for the proper operation of the heat pump.
- Avoid storing chemical containers near the heat pump. The chemicals can cause equipment damage.
- Avoid placing objects near or on top of the heat pump. This includes shrubbery and lawn furniture. These objects will reduce performance and efficiency and hinder maintenance access.






(Top View) TropiCal<sup>®</sup> T170




# (HeatWave SuperQuiet® SQ120R, SQ125, SQ145, SQ166R and SQ225)

## (TropiCool® TC1500)




## (TropiCal<sup>®</sup> T035, T055 and T075) (TropiCool<sup>®</sup> TC500)




# (TropiCal® T090, T115 and T135)

## (TropiCool® TC1000)



## (TropiCal<sup>®</sup> T170)



## 1.4 Plumbing

## 1.4.a Plumbing Requirements

## **NOTICE**

Failure to heed the following may result in damage to equipment.

- Do not use glue on the threaded portion of the equipment's unions. A glued-in-place union will prevent the equipment from being properly winterized.
- The heat pump must receive water flow within the specified minimum ranges under worst-case conditions such as a fouled water filter.
- Failure to provide clean filtered water to the heat pump can void the product warranty.
- Water flow exceeding maximum flow rates will negatively affect the total pool filtration performance and may damage the heat pump. This will not be covered under the equipment warranty. See "*Water Flow Rates*" on page 11.
  - Install a bypass valve whenever water-flow may exceed the maximum rating.
    - See "Bypass Valve Kit (#STK0135)" on page 82.
    - For additional guidance testing water flow rates, please contact AquaCal\*.
- A safety-enhancing "Over Temperature Alarm" kit is strongly recommended for all spa applications. See "Over Temperature Alarm Kit" on page 83.


## 1.4.b Plumbing Diagrams

Plumbing diagrams are provided in this section as a planning guide to the sequence of equipment, valves, and fittings.

- The basic plumbing configurations for typical installations are shown.
- If the installation does not closely follow any of the supplied plumbing diagrams, AquaCal® Technical Support is available for installation advice and guidance.
- Confirm water provided to the heat pump is clean and filtered.


#### Heat Pump with water flows equal or less than the maximum listed flow rate

See "Water Flow Rates" on page 11.




## Heat Pump with water flows greater than the maximum listed flow rate


See "Water Flow Rates" on page 11.




## Heat Pump with Spillover Spa (One filter Pump)




#### Heat Pump with Spillover Spa (Two filter Pumps)




## Heat Pump with Solar Panels in Plumbing Circuit



#### Heat Pump with Gas Heater backup



#### **Multiple Air Source Heat Pumps**



## 1.4.c Water Connections to Heat Pump

- Heat Pump union sizes are specified on diagrams.
- Connections to site plumbing are made via PVC solvent cement to the female slip socket of the plumbing unions.
- Plumbing unions are available from AquaCal®.


## **NOTICE**

Failure to heed the following may result in damage to equipment.


• Do not use glue on the threaded portion of the equipment's unions. A glued-in-place union will prevent the equipment from being properly winterized.

# HeatWave SuperQuiet® SQ120R, SQ125, SQ145, SQ166R, SQ225


## TropiCool® TC1500




## TropiCool® TC500




## TropiCool® TC1000




## TropiCal<sup>®</sup> T035, T055, T075



## TropiCal<sup>®</sup> T090, T115, T135



## TropiCal<sup>®</sup> T170




#### 1.4.d In-Line Chlorine Feeders

Place in-line chlorinators downstream from the heat pump and as low in elevation as possible.

- If an erosion type feeder is used, it is recommended that a Hartford Loop be installed to protect internal heat pump components.
- A Hartford Loop is not necessary with a Salt Chlorine Generator.

#### **Heat Pump with Hartford Loop**



#### 1.4.e Water Flow Rates

Maintain water flow rates as indicated. Please note, these specifications relate to the heat pump only. Code-specified whole system turnover rates must be satisfied.

## NOTICE

Failure to heed the following may result in damage to equipment.

• Water flow exceeding maximum flow rates will negatively affect the total pool filtration performance and may damage the heat pump. This will not be covered under the equipment warranty.

MODEL HEAT EXCHANGER TYPE		FLOW F	RATES
MODEL	HEAT EXCHANGER TYPE	MINIMUM	MAXIMUM
SQ120R	Titanium ThermoLink®	30 GPM (113.6 L/min)	70 GPM (265 L/min)
SQ125	Titanium ThermoLink®	30 GPM (113.6 L/min)	70 GPM (265 L/min)
SQ145	Titanium ThermoLink®	30 GPM (113.6 L/min)	70 GPM (265 L/min)
SQ150VS	Titanium ThermoLink®	30 GPM (113.6 L/min)	70 GPM (265 L/min)
SQ166R	Titanium ThermoLink®	30 GPM (113.6 L/min)	70 GPM (265 L/min)
SQ225	Titanium ThermoLink®	30 GPM (113.6 L/min)	70 GPM (265 L/min)
T035	Titanium Tube-in-Tube	20 GPM (75.7 L/min)	45 GPM (170 L/min)

MODEL HEAT EXCHANGER TYPE		FLOW F	RATES
MODEL	HEAT EXCHANGER TITE	MINIMUM	MAXIMUM
T055	Titanium Tube-in-Tube	20 GPM (75.7 L/min)	45 GPM (170 L/min)
T075	Titanium Tube-in-Tube	20 GPM (75.7 L/min)	45 GPM (170 L/min)
T090	Titanium ThermoLink®	30 GPM (113.6 L/min)	70 GPM (265 L/min)
T115	Titanium ThermoLink®	30 GPM (113.6 L/min)	70 GPM (265 L/min)
T135	Titanium ThermoLink®	30 GPM (113.6 L/min)	70 GPM (265 L/min)
T170	Titanium Tube-in-Tube	30 GPM (113.6 L/min)	70 GPM (265 L/min)
TC500	Titanium Tube-in-Tube	20 GPM (75.7 L/min)	45 GPM (170 L/min)
TC1000	Titanium ThermoLink®	30 GPM (113.6 L/min)	70 GPM (265 L/min)
TC1500	Titanium ThermoLink®	30 GPM (113.6 L/min)	70 GPM (265 L/min)

#### PLEASE NOTE -

If minimum flow rates are not met, heat pump performance is reduced and performance will suffer. Internal safety devices may deactivate the heat pump with the following errors:

- HIGH PRESSURE FAULT
- HP5 SYSTEM LOCKOUT
- LOW PRESSURE FAULT
- LP5 SYSTEM LOCKOUT
- Operate water filtration devices per manufacturer's specifications. Dirty filters can cause a reduction of water flow to the heat pump. An increase of 7-10 psi (48 to 69 kPa) higher than the clean filter pressure typically reduces flow rates. This requires the filter to be cleaned or back-washed.
- Keep baskets free of debris. A large quantity of debris in the pump and skimmer baskets can reduce water flow.
- Check for improper valve settings. A partially closed valve after the filter, or a full-open bypass around the heat pump, will cause insufficient water flow through the heat pump.
- The maximum static pressure (or operating pressure) is 50 psi (345 kPa). These specifications relate to the heat pump only.
- Code-specified whole system turnover rates must be satisfied.

#### 1.4.f Adjusting Water Flow Using ΔT (Delta-T)

The Delta-T is the temperature difference between the water temperatures entering and leaving the heat pump. The equipment can be fine-tuned for maximum performance by balancing water flow rates to maintain an ideal  $\Delta T$ .

## The adjustment procedure must be completed with the unit in heating mode.

- Installed temperature ports are required to perform the following procedures.
- These ports are typically located on the pool in and pool out water lines approximately six inches away from the heat pump.

#### PLEASE NOTE -

- The installation of temperature ports is required for all commercial applications.
- The installation of temperature ports is strongly recommended for residential installations.
  - See "Temperature Port Kit (#STK0096)" on page 84.

- 1. Adjust the thermostat to its lowest setting with the unit in heating mode.
- 2. Deactivate the water filtration pump.
- 3. Confirm that the filters leading to the heat pump are clean.
- 4. Adjust the valves controlling water headed towards the heat pump to the half-open position.
- 5. Adjust the valves controlling water leading away from the heat pump to a fully open position.
- 6. Activate the pool water filtration pump.
- 7. Slowly raise the thermostat temperature until the heat pump activates.
  - After a three-minute delay, the heat pump's compressor will start.
- 8. With the heat pump running, confirm the filtration pump is operating properly with adequate flow and no short cycling.
- 9. Wait for water temperatures to stabilize (approximately 5 minutes).
- 12. Adjust valves in the following order using the temperature chart provided.
  - a. Adjust the valve that controls water exiting the heat pump until the correct temperature differential is achieved. Match the temperature measured with a temperature probe to the chart.
  - b. Wait for water temperatures to stabilize. Then check the temperature again. Re-adjust the valve as needed.
- 13. Mark valves at these positions for future reference.

HEAT EXCHANGER TYPE	MODEL	TEMPERATURE
Titanium ThermoLink®	SQ120R	3° to 7° F
	5Q120K	(1.7° C to 3.9° C)
Titanium ThermoLink®	SQ125	3° to 7° F
	5Q123	(1.7° C to 3.9° C)
Titanium ThermoLink®	SQ145	3° to 7° F
	3Q143	(1.7° C to 3.9° C)
Titanium ThermoLink®	CO150VC	3° to 7° F
	SQ150VS	(1.7° C to 3.9° C)
Titanium ThermoLink®	SQ166R	3° to 8° F
	SQ100K	(1.7° C to 4.4° C)
Titanium ThermoLink®	50225	4° to 9° F
	SQ225	(2.2° C to 5° C)
Tube-in-Tube	T035	1° to 4° F
	1033	(.5° C to 2.2° C)
Tube-in-Tube	T055	2° to 5° F
	T055	(1.1° C to 2.8° C)



**Temperature Port** 

HEAT EXCHANGER TYPE	MODEL	TEMPERATURE
Tube-in-Tube	T075	3° to 7° F
	10/3	(1.7° C to 3.9° C)
Titanium ThermoLink®	T090	3° to 6° F
	1090	(1.7° C to 3.3° C)
Titanium ThermoLink®	T115	3° to 7° F
	1113	(1.7° C to 3.9° C)
Titanium ThermoLink®	T135	4° to 8° F
	1133	(2.2° C to 4.4° C)
Titanium Tube-in-Tube	T170	3° to 7° F
	1170	(1.7° C to 3.9° C)
Titanium Tube-in-Tube	TC500	2° to 5° F
	10300	(1.1° C to 2.8° C)
Titanium ThermoLink®	TC1000	2° to 5° F
	101000	(1.1° C to 2.8° C)
Titanium ThermoLink®	TC1500	3° to 7° F
	101300	(1.7° C to 3.9° C)

Table 1 - Temperature Chart

#### PLEASE NOTE -

- Temperature differences are based on pool water temperatures of  $69^\circ$  to  $75^\circ$  F. (20.5° to 23.8° C)
- For water temperatures outside this range, contact AquaCal\*. See "Contacting AquaCal AutoPilot, Inc." on page 1.

## 1.4.g Maintaining Ability to Winterize

Do not glue the threaded portion of the unions. The unions are used to decouple the heat pump from the plumbing system during hard freeze conditions.

## **NOTICE**

Failure to heed the following may result in damage to equipment.

• Do not use glue on the threaded portion of the equipment's unions. A glued-in-place union will prevent the heat pump from being properly winterized.

## 1.4.h Adjusting Water Pressure Switch

Adjust the water pressure switch when heat pump attempts to operate without water flow.

Before attempting any adjustments confirm the following:

- The filter is clean.
- Filter pump is operating.
- The valves are set to direct the appropriate amount of water through the heat pump. See "*Water Flow Rates*" on page 11.
- "NO POOL/SPA WATER FLOW" is displayed (or displays intermittently).

# **⚠** DANGER

Failure to heed the following will result in injury or death.

- RISK OF ELECTRICAL SHOCK FROM ENERGY STORED IN CAPACITORS MODELS EQUIPPED WITH VARIABLE FREQUENCY COMPRESSOR DRIVES STORE ELECTRICITY EVEN AFTER THE POWER HAS BEEN DEACTIVATED AT THE POWER BREAKER. Wait for 2 minutes after the shut down of equipment before servicing.
- Deactivate power while routing wiring to control board.
- Follow all National Electric Codes (NEC) and/or State and Local guidelines.

# **AWARNING**


Failure to heed the following may result in injury or death.

• Water Pressure Switch adjustment procedure to be performed by experienced service personnel only; procedure must not be attempted by individuals lacking adequate electrical and mechanical experience.

## NOTICE

Failure to heed the following may result in damage to equipment.

- If the heat pump continues to operate after a water pressure switch adjustment, deactivate equipment and perform additional troubleshooting.
- 1. Remove heat pump access panel.
- 2. Locate the water pressure switch. It will be outside and along the bottom edge of the electrical enclosure. The exact location varies by model.
- 3. Activate the filter pump.
- 4. Apply power to heat pump.
- Slowly rotate the adjustment wheel on the switch. Keep turning the wheel until the heat pump indicates it is receiving water. The display will no longer indicate "NO POOL/SPA WATER FLOW".
- Deactivate filter pump. If correctly adjusted, the heat pump will deactivate and the display will show "NO POOL/SPA WATER FLOW".
- 7. Re-install heat pump access panel.



- 8. If the heat pump continues to operate without water flow, the installation of a grid flow switch may be required.
  - This can become necessary if the heat pump is installed below the elevation of the body of water to be heated or cooled. The standing pressure from the water can cause the water pressure switch to activate when the circulation pump is off. Therefore a water <u>flow</u> switch must be used in place of a water <u>pressure</u> switch to determine if incoming water is being sent to the heat pump. See "Grid Flow Switch (# 0040S)" on page 83.
- 9. If the heat pump continues to operate without water flow, contact AquaCal\*.

#### 1.5 Electrical

## 1.5.a Electrical Requirements



Failure to heed the following will result in injury or death.

- RISK OF ELECTRICAL SHOCK FROM ENERGY STORED IN CAPACITORS MODELS EQUIPPED
  WITH VARIABLE FREQUENCY COMPRESSOR DRIVES STORE ELECTRICITY EVEN AFTER THE
  POWER HAS BEEN DEACTIVATED AT THE POWER BREAKER. Wait for 2 minutes after the shut down
  of equipment before servicing.
- Deactivate power while routing wiring to control board.
- Follow all National Electric Codes (NEC) and/or State and Local guidelines.

## **AWARNING**

Failure to heed the following may result in injury or death.

- The information contained in this section is intended for use by qualified electricians familiar with electrical service-industry safety standards and methods.
- Locate the equipment disconnect as near to the heat pump as possible. Always satisfy applicable codes and standards.
- Never mount power-disconnects directly to the heat pump.
- In sizing power wiring, be especially aware of up-sizing requirements necessary due to wiring distances. Always satisfy applicable codes and standards.
- AquaCal\* heat pumps are designed to use copper conductors, only. Do not use aluminum wire.
- If multiple heat pumps are on-site, confirm that the multiple heat pump configuration has been utilized. See "Connecting Multiple Heat Pumps (Primary / Secondary)" on page 39. This will prevent multiple heat pumps attempting to start at the same time, causing an excessive power drop at start-up.

#### Electrical Standards

Standards	Title
NFPA 70, Nat'l Elec. Code 2017	The electrical installation must conform to the current version of the National Electric Code (NEC), and all applicable local and state codes
IEC 60335-1	Household and similar electrical appliances - Safety - General Requirements
IEC 60335-2	Household and similar electrical appliances - Safety – Particular requirements for electrical heat pumps, air-conditioners, and dehumidifiers
UL 1995 & CSA C22.2 No. 236-15	Standard for Safety - Heating and cooling equipment

Table 2 - Standards

## **Grounding and Bonding**

Follow local code requirements for proper grounding and bonding of heat pump equipment.

• A bonding lug has been provided on the lower right-hand corner of the front access panel.

## Surge Suppression

The use of approved commercial surge protectors is strongly recommended.

## Sizing the Electrical Service

Refer to equipment data plate for specific information required to size electrical service and over-current protection of the heat pump. Sizing is based on data plate information, wire size, wiring devices, and over-current protection per applicable local codes and standards. See "*Identifying Model Specifications*" on page 79.

## Minimum and Maximum Operating Voltage

The heat pump must operate within specified voltages.

## **NOTICE**

Failure to heed the following may result in damage to equipment.


- Operating equipment under higher or lower voltage conditions may result in damage to your compressor, motors or other electrical components. This damage will not be covered by the product warranty.
- 1. Measure site voltage. The site voltage **MUST** be measured under "FULL LOAD" conditions. Activate all equipment using the same electrical panel as the heat pump.
- 2. If measured site voltage is outside listed ranges, immediately deactivate equipment until site conditions have been corrected. If unsure of heat pump equipment rating, please see "*Identifying Model Specifications*" on page 79.

Equipment Rating	Minimum Site Voltage	Maximum Site Voltage
A Voltage		
(208 to 230 Volts)	200 Volts	253 Volts
Single Phase 60 hertz		
B Voltage		
(208 to 230 Volts)	200 Volts	253 Volts
Three Phase 60 hertz		
D Voltage		
(380 to 420 Volts)	361 Volts	441 Volts
Three Phase 50 hertz		
E Voltage		
(380 Volts)	361 Volts	399 Volts
Three Phase 60 hertz		
G Voltage		
(460 Volts)	437 Volts	483 Volts
Three Phase 60 hertz		
H Voltage		
(200 to 240 Volts)	180 Volts	264 Volts
Single Phase 50 hertz		


## 1.5.b Incoming Power Access Holes

(HeatWave SuperQuiet® SQ120R, SQ125, SQ145, **SQ166R and SQ225)** 


(TropiCool® TC1500)




(TropiCal® T035, T055 and T075) (TropiCool® TC500)



(TropiCal® T090, T115 and T135) (TropiCool® TC1000)



(TropiCal<sup>®</sup> T170)




# **⚠** DANGER


Failure to heed the following will result in injury or death.

- RISK OF ELECTRICAL SHOCK FROM ENERGY STORED IN CAPACITORS MODELS EQUIPPED WITH VARIABLE FREQUENCY COMPRESSOR DRIVES STORE ELECTRICITY EVEN AFTER THE POWER HAS BEEN DEACTIVATED AT THE POWER BREAKER. Wait for 2 minutes after the shut down of equipment before servicing.
- Deactivate power while routing wiring to control board.
- Follow all National Electric Codes (NEC) and/or State and Local guidelines.


## HeatWave SuperQuiet® TropiCool® TC1500




## TropiCal<sup>®</sup> T035, T055 and T075 TropiCool<sup>®</sup> TC1000



## TropiCool® TC500



## TropiCal<sup>®</sup> T170



## 1.5.d Verifying Transformer Setting

Transformer voltage must be confirmed and set correctly depending on the measured voltage found on the site. Incorrect settings may cause heat pump damage. The following procedure will allow the installer to set the heat pump's transformer for the appropriate site voltage.



Failure to heed the following will result in injury or death.


- RISK OF ELECTRICAL SHOCK FROM ENERGY STORED IN CAPACITORS MODELS EQUIPPED
  WITH VARIABLE FREQUENCY COMPRESSOR DRIVES STORE ELECTRICITY EVEN AFTER THE
  POWER HAS BEEN DEACTIVATED AT THE POWER BREAKER. Wait for 2 minutes after the shut down
  of equipment before servicing.
- Deactivate power while routing wiring to control board.
- Follow all National Electric Codes (NEC) and/or State and Local guidelines.

# **AWARNING**

Failure to heed the following may result in injury or death.

- The information contained in this section is intended for use by qualified technicians, familiar with electrical service-industry safety standards and methods.
- 1. Turn heat pump on by adjusting the thermostat to call for heating or cooling. If more than one heat pump is on-site, turn them all on. Allow time for all heat pump compressors to activate.
- 2. Measure the running site voltage.
- 3. Confirm transformer tap is set for the measured site voltage. If more than one voltage tap is shown, select the voltage nearest to the running site voltage.

Example of heat pump transformer (Varies between models)



#### PLEASE NOTE -

- If more than one voltage is shown on the equipment's data plate, the factory default setting is usually the higher voltage on the transformer.
- As an example, a "208/230" voltage will be set to "240" from the factory.

## 1.5.e Three-Phase Adjustment



Failure to heed the following will result in injury or death.

- RISK OF ELECTRICAL SHOCK FROM ENERGY STORED IN CAPACITORS MODELS EQUIPPED WITH VARIABLE FREQUENCY COMPRESSOR DRIVES STORE ELECTRICITY EVEN AFTER THE POWER HAS BEEN DEACTIVATED AT THE POWER BREAKER. Wait for 2 minutes after the shut down of equipment before servicing.
- Deactivate power while routing wiring to control board.
- Follow all National Electric Codes (NEC) and/or State and Local guidelines.



Failure to heed the following may result in injury or death.

• The information contained in this section is intended for use by qualified technicians, familiar with electrical service-industry safety standards and methods.

If a three-phase unit fails to operate at start-up, the orientation of the line voltage "field" wiring may need to be adjusted.

- The phase monitor is located inside the electrical panel.
- 1. Deactivate power to the unit. Confirm that power is off to all three legs using an electrical test meter set for the correct voltage.
- 2. Switch position of the incoming power wires at each leg as follows, re-connect power and attempt to restart the unit. If the unit fails to start, disconnect power. Verify off and proceed to the next leg.
  - Switch incoming power wires at L1 and L2 on the line side to the contactor.
  - Switch incoming power wires at L1 and L3 on the line side to the contactor.
  - Switch incoming power wires at L2 and L3 on the line side to the contactor.
- 3. When heat pump starts, disconnect power and verify off. Then confirm all line voltage connections are securely tightened. Reconnect power.
  - If the heat pump does not start, contact AquaCal\* for further assistance. See "Contacting AquaCal AutoPilot, Inc." on page 1.

1.5.f Schematic Location

Schematics are located on the inside of the electrical panel.

## Three-Phase Monitor



## 1.6 External Equipment

## 1.6.a Connecting a Call Flex

To support a direct connection to a call flex accessory, AquaCal\* heat pumps are equipped with optional terminal blocks on the microprocessor. The microprocessor is located on the low-voltage side of the electrical enclosure.

The call flex accessory can override a circulation pump to provide water flow to the heat pump when the set temperature is not met. For ordering information on the accessory, see "Call Flex Accessory (# 0030-LEDS)" on page 83.

#### **Connecting a Call Flex**



Failure to heed the following will result in injury or death.

- RISK OF ELECTRICAL SHOCK FROM ENERGY STORED IN CAPACITORS MODELS EQUIPPED WITH VARIABLE FREQUENCY COMPRESSOR DRIVES STORE ELECTRICITY EVEN AFTER THE POWER HAS BEEN DEACTIVATED AT THE POWER BREAKER. Wait for 2 minutes after the shut down of equipment before servicing.
- Deactivate power while routing wiring to control board.
- Follow all National Electric Codes (NEC) and/or State and Local guidelines.

# **AWARNING**

Failure to heed the following may result in injury or death.


- This section is only for qualified installers who are familiar with the swimming pool and spa safety standards.
- The installer must be familiar with service industry techniques.

## **NOTICE**


Failure to heed the following may result in damage to equipment.


- The wire size connecting the controller must be 22-gauge (minimum), 2-conductor, low-voltage wire.
- 1. Deactivate power to heat pump.
- 2. Remove heat pump electrical access panel.
- Route 22-gauge (minimum), 2-conductor, low-voltage wires to the low voltage side of the electrical enclosure. Follow all National Electric Codes (NEC) unless State or Local guidelines supersede.
- 4. Connect the controller wires to the port labeled "Call Flex" on the microprocessor as indicated.
- 5. Reattach heat pump access panel.
- 6. Apply power to heat pump.
- 7. Configure the heat pump to indicate an installed Call Flex. See "*Configure Call Flex*" on the next page.


#### **Connection Points to the Microprocessor**





## Enter "Installer Menus", then proceed

























## 1.6.b Connecting a Chlorinator

To support an AutoPilot® ChlorSync chlorinator, select AquaCal® heat pumps are equipped with a power supply outlet on the front of the unit. The chlorination cell can be plugged directly into the heat pump without the need for a ChlorSync power supply.

# **⚠** DANGER

Failure to heed the following will result in injury or death.


- RISK OF ELECTRICAL SHOCK FROM ENERGY STORED IN CAPACITORS MODELS EQUIPPED WITH VARIABLE FREQUENCY COMPRESSOR DRIVES STORE ELECTRICITY EVEN AFTER THE POWER HAS BEEN DEACTIVATED AT THE POWER BREAKER. Wait for 2 minutes after the shut down of equipment before servicing.
- Deactivate power while routing wiring to control board.
- Follow all National Electric Codes (NEC) and/or State and Local guidelines.




Failure to heed the following may result in injury or death.

- This section is only for qualified installers who are familiar with the swimming pool and spa safety standards.
- The installer must be familiar with service industry techniques.

- 1. Deactivate power to heat pump.
- 2. Route the ChlorSync cell cord so that it is protected from possible damage by lawn equipment or foot traffic. If desired, the cord may be secured to plumbing or electrical conduit using tie wraps (not included).
- 3. Align and insert the six (6) pin cell cord connector to the heat pump's power supply port as indicated.
- 4. Turn the round nut until it locks the connector in place.
- 5. Apply power to heat pump.



**ChlorSync Connectioned to Heat Pump** 



## 1.6.c Connecting External Controllers to Heat Pump

To support a direct connection to an external controller, AquaCal\* heat pumps are equipped with optional removable terminal blocks on the microprocessor. The microprocessor is located on the low-voltage side of the electrical enclosure.



Failure to heed the following will result in injury or death.

- RISK OF ELECTRICAL SHOCK FROM ENERGY STORED IN CAPACITORS MODELS EQUIPPED WITH VARIABLE FREQUENCY COMPRESSOR DRIVES STORE ELECTRICITY EVEN AFTER THE POWER HAS BEEN DEACTIVATED AT THE POWER BREAKER. Wait for 2 minutes after the shut down of equipment before servicing.
- Deactivate power while routing wiring to control board.
- Follow all National Electric Codes (NEC) and/or State and Local guidelines.



Failure to heed the following may result in injury or death.

- This section is only for qualified installers who are familiar with the swimming pool and spa safety standards.
- The installer must be familiar with service industry techniques.

## **NOTICE**

Failure to heed the following may result in damage to equipment.

• Do not use an electric heater connection on external controllers for heat pump wiring. This can cause damage to external controllers, heat pumps, and pad equipment. This damage is NOT covered by warranty.




- The wire size connecting the external controller to the heat pump must be 22-gauge, 2-conductor, low-voltage wire.
- Use the two middle data lines on the external controller's standard communication port (RS-485). Do not use the outside power or ground connection on the port.

#### c.1 Connecting Smart Bus Controllers

#### **Wire Connections**

- 1. Deactivate power to heat pump and external controller.
- 2. Remove electrical access panels on the heat pump and external controller.
- 3. Route 22-gauge, 2-conductor, low-voltage wires from the external controller communication port (com port) to the low voltage side of the heat pump's electrical enclosure. Do not use the power or ground wire.

# **External Controller Communication Port**



- 4. Connect control wires to the heat pump's "Port B" of the microprocessor as indicated. See Figure 1 and Figure 2.
  - It is OK to double up wires at the external controller connection if necessary.
  - If, for example, the external controller is using the data port for an indoor controller, add wires to the existing configuration. Connectors can be removed from terminals for ease in connecting wires. See Figure 3




Figure 1

Typically a smart bus controller will have four wires on its smart bus for a heat pump. The power and ground (usually the 1st and 4th wire) are not used.






Figure 3

Figure 2

5. If dip-switch settings are required, configure them on the external controller now.



Failure to heed the following will result in injury or death.

• Deactivate power to the external controller while setting dip-switches

## Example - Jandy AquaLink®:

This external controller has dip switches. Confirm they are properly positioned to operate a heat pump.

- Set dip-switch "S2" #1 to "ON". The solar option is to be used for the heat pump.
- Check Jandy documentation for any further dip switch settings.



6. If additional sensors are required on the external controller, install them on the external controller now.

#### Example - Pentair EasyTouch® and Pentair IntelliTouch®:


Some controllers require an additional sensor be connected to the external controller's power supply circuit board at the solar connection point. The sensor is not used but will show an error if not connected.





- 7. Reinstall electrical access panels on both the heat pump and external controller.
- 8. Reactivate power to heat pump and external controller.
- 9. Configure the heat pump to accept external controller signal. See "Configure for Smart Bus Controller" on the facing page.


## Configure for Smart Bus Controller


Enter "Installer Menus", then proceed





























- 10. If after 45 seconds, the heat pump displays a "SMART COMM FAULT":
  - A. **Confirm dip switches** If external controller uses dip switches, confirm switches are in the correct position. Otherwise, proceed to confirm wiring.
    - a. Deactivate power to the external controller.
    - b. Remove access panel on external controller.
    - c. Check the external controller manual for proper dip switch positioning and confirm dip switches.
    - d. Reinstall electrical access panel.
    - e. Reactivate power to the controller.
    - f. If the fault persists, proceed to confirm wiring.
  - B. **Confirm wiring -** Confirm wires are oriented properly on the heat pump's "Port B" of the microprocessor.
    - a. Deactivate power to heat pump and external controller.
    - b. Remove the access panel on the heat pump.
    - c. Reverse wires on "Port B".
    - d. Reinstall electrical access panel.
    - 7. Reactivate power to the controller.
    - 8. Reactivate power to the heat pump.
  - C. If fault continues to occur, check with the manufacturer of the external controller for additional advice on using a heat pump with the controller.
- 11. After establishing a connection from the external controller to the heat pump, further programming will be required at the external controller.
  - See external controller manuals or contact installer or manufacturer of that product.

#### c.2 Connecting Two-wire Controllers (with internal thermostat)

#### PLEASE NOTE

2-Wire controllers are not designed to control chiller operation.

For full functionality, the Heat and Cool, and Cool Only heat pumps must use an external controller that has a SMART bus connection. Check with the external controller manufacturer for more information.

# **⚠** DANGER

Failure to heed the following will result in injury or death.

- RISK OF ELECTRICAL SHOCK FROM ENERGY STORED IN CAPACITORS MODELS EQUIPPED WITH VARIABLE FREQUENCY COMPRESSOR DRIVES STORE ELECTRICITY EVEN AFTER THE POWER HAS BEEN DEACTIVATED AT THE POWER BREAKER. Wait for 2 minutes after the shut down of equipment before servicing.
- Deactivate power while routing wiring to control board.
- Follow all National Electric Codes (NEC) and/or State and Local guidelines.

## **A**WARNING

Failure to heed the following may result in injury or death.

- This section is only for qualified installers who are familiar with the swimming pool and spa safety standards.
- The installer must be familiar with service industry techniques.
- 1. Deactivate power to heat pump.
- 2. Remove heat pump electrical access panel.
- 3. Route 22-gauge (minimum), 2-conductor, low-voltage wires from the controller to the low voltage side of the heat pump's electrical enclosure. Follow all National Electric Codes (NEC) unless State or Local guidelines supersede.
- 4. Connect the controller wires to the microprocessor port labeled "Ext Controller" with the terminals labeled "Y" and "Z" as follows. See Figure 4.
  - Connect one wire to "Y".
  - Connect other wire to "Z".
  - The polarity of the wire is not important.
- 5. Reattach heat pump access panel.
- 6. Apply power to heat pump.
- 7. Configure the heat pump to accept a 2-wire external controllers signal as shown. See "*Configure 2-wire controller*" on the next page.








Figure 4


## Enter "Installer Menus", then proceed





























### 1.6.d Connecting Gas Backup Heater to Heat Pump

To support a direct connection to a gas backup heater, AquaCal® heat pumps are equipped with optional terminal blocks on the microprocessor. The microprocessor is located on the low-voltage side of the electrical enclosure.

#### PLEASE NOTE -

If the heat pump is connected and using an external controller with a SMART bus connection, the gas backup option is not available. The gas backup should be connected directly to the external controller.



Failure to heed the following will result in injury or death.

- RISK OF ELECTRICAL SHOCK FROM ENERGY STORED IN CAPACITORS MODELS EQUIPPED WITH VARIABLE FREQUENCY COMPRESSOR DRIVES STORE ELECTRICITY EVEN AFTER THE POWER HAS BEEN DEACTIVATED AT THE POWER BREAKER. Wait for 2 minutes after the shut down of equipment before servicing.
- Deactivate power while routing wiring to control board.
- Follow all National Electric Codes (NEC) and/or State and Local guidelines.

# **▲**WARNING

Failure to heed the following may result in injury or death.

- This section is only for qualified installers who are familiar with the swimming pool and spa safety standards.
- The installer must be familiar with service industry techniques.

## **NOTICE**

Failure to heed the following may result in damage to equipment.

- The wire size connecting the gas heater to the heat pump must be 22-gauge (minimum), 2-conductor, low-voltage wire.
- Use direct connection (**dry contact**) provided on the microprocessor for the gas heater.
- Failure to follow the manufacturer's installation requirements for a fireman (cool down) switch may result in damage to the gas heater.

#### **Connections**

- 1. Deactivate power to heat pump and gas heater.
- 2. Remove heat pump and gas heater's electrical access panels. Follow all National Electric Codes (NEC) unless State or Local guidelines supersede.
- 3. Route 22-gauge (minimum), 2-conductor, low-voltage wires from the gas heater to the low voltage side of the heat pump's electrical enclosure. Depending on the gas heater's circuit boards, use the following connection points from the gas heater.
  - Use the "Com" and "Pool" connection points from the gas heater. See Figure 5.
  - Or replace the jumper wire from the Fireman's Switch on the gas heater with two wires leading to the heat pump. See Figure 6.

## Gas Heater's Pool and Common Connection




Figure 5

#### Gas Heater's Fireman Switch




Figure 6

If the Gas Heater requires a fireman (cool down) switch, it is the installer's responsibility to ensure this requirement is met.


Failure to follow the manufacturer's installation requirements may result in damage to the gas heater.

### PLEASE NOTE

Do not use a smart connection data comm port from the gas heater.

- 4. Connect the controller wires to the port labeled "Gas" on the microprocessor as indicated.
- 5. Reattach heat pump and gas heater access panels.
- 6. Apply power to heat pump and gas heater.
- 7. Configure gas heater to accept a two-wire remote control signal. See gas heater's manual for specifics on this procedure.
- 8. Configure gas backup mode on heat pump. See "*Configuring Gas Backup*" below.

# Dry Contact Connection Points to the Microprocessor





#### **Configuring Gas Backup**

There are two different ways the gas backup heater can be configured.


- 24-hour mode commonly used for commercial applications
  - The circulation pump operates continuously.
  - The gas heater will activate if the water temperature falls two degrees below the set temperature. When the set temperature is reached, the gas heater will be deactivated. See "Configure for 24-Hour Mode" below.
  - The Heat Pump will continue to maintain the set temperature.
- Scheduled mode commonly used for residential applications
  - The circulation pump operates on the circulation pumps regular on-off schedule.
  - The gas heater will activate as needed to ensure that the desired temperature will be reached within the circulation pumps schedule. The gas heater will deactivate when the water is warm enough to allow the heat pump to finish within schedule. The heat pump will then continue to heat the water till the set temperature is reached. See "Configure for Scheduled Mode" on page 37.


#### **Configure for 24-Hour Mode**


































## **Configure for Scheduled Mode**




























## 1.6.e Connecting Multiple Heat Pumps (Primary / Secondary)

Up to 16 heat pumps can be connected and controlled from a primary heat pump.

There are two reasons for using a multiple heat pump configuration:

- 1. Controlling multiple heat pumps from one location; the primary heat pump.
- 2. Preventing heat pumps from starting up at the same time and causing an excessive power draw on the electric circuit.

# **⚠** DANGER

Failure to heed the following will result in injury or death.

- RISK OF ELECTRICAL SHOCK FROM ENERGY STORED IN CAPACITORS MODELS EQUIPPED WITH VARIABLE FREQUENCY COMPRESSOR DRIVES STORE ELECTRICITY EVEN AFTER THE POWER HAS BEEN DEACTIVATED AT THE POWER BREAKER. Wait for 2 minutes after the shut down of equipment before servicing.
- Deactivate power while routing wiring to control board.
- Follow all National Electric Codes (NEC) and/or State and Local guidelines.

# **AWARNING**

Failure to heed the following may result in injury or death.

- This section is only for qualified installers who are familiar with the swimming pool and spa safety standards.
- The installer must be familiar with service industry techniques.

## **NOTICE**

Failure to heed the following may result in damage to equipment.

- The wire size connecting the heat pumps must be 22-gauge, 2-conductor, low-voltage wire. Be sure that the size of the wire will allow at least two wires per connection point.
- Do not attempt to connect heat pump equipment in multiple configurations with previous HP7 and HP7R versions of the microprocessor. See Figure 7. No onboard port is provided for heat pumps with these microprocessor versions. An Automatic Sequencing Controller (ASC) accessory is required for those types of heat pumps.

# DO NOT CONNECT HP7 or HP7R boards



Figure 7

## **Connecting Multiple Heat Pumps**

- 1. Choose one unit to be the lead (or primary) unit. This is typically a unit that can be accessed easily when temperature adjustments are needed.
  - Note The primary unit can be connected to an external controller via the "smart bus" (PORT B) connection point if desired.
- 2. Deactivate power to heat pumps.
- 3. Remove electrical access panels.
- 4. Route 22-gauge, 2-conductor, low-voltage wires to the low voltage sides of the electrical enclosures. Follow all National Electric Codes (NEC) and / or State and Local guidelines.

# Dry Contact Connection Points to the Microprocessor




Figure 8

- 5. Connect the first secondary heat pump's wires to the unit selected as the primary heat pump's.
- 6. Use "Port C" on the control boards as indicated. Connecting the "Y" to the "Y" and the "B" to the "B" on each heat pump's port "C" connection point. The "G" and "R' connection points are not used. See Figure 8.
- 7. Connect any additional heat pumps as indicated, doubling up the wires as shown. See Figure 9. Confirm the same color wires connect to the same wires on each heat pump ("Y" to "Y" and "B" to "B"). Up to 16 heat pumps can be controlled by one heat pump.
- 8. Label the heat pumps appropriately as a primary unit and secondary units (Primary, Secondary 01, Secondary 02, etc.) to simplify configuration and future operation.
- 9. Reattach access panels.
- Apply power to primary heat pump.
   Confirm the mode is set to "SYSTEM OFF".
- 11. Apply power to the next heat pump and confirm the mode is set to "SYSTEM OFF". Do this for each heat pump.
- 12. Program heat pumps with assigned addresses. See "*Configuring Multiple Heat Pumps*" below.

## Multiple Heat Pump Connection Points to "Port C"






Figure 9


#### **Configuring Multiple Heat Pumps**

#### **Primary Heat Pump**


Confirm the first connected heat pump is designated as the primary unit.






























## **Secondary Heat Pumps**


Go to the next connected heat pump and configure it as a secondary unit with a heat pump address of "01". Each additionally connected heat pump will require a unique heat pump address ("02", "03", etc.)








































## 1.6.f Connecting a Pool/Spa Switching Relay

A direct connection to an external flow relay switch has been provided on the terminal microprocessor. A pool/spa relay switch will automatically change between the pool and spa thermostat depending on the position of the plumbing valves.

- When water flows to the pool, the pool thermostat will be used.
- When water flows to the spa, the spa thermostat will be used.

# **⚠** DANGER

Failure to heed the following will result in injury or death.

- RISK OF ELECTRICAL SHOCK FROM ENERGY STORED IN CAPACITORS MODELS EQUIPPED
  WITH VARIABLE FREQUENCY COMPRESSOR DRIVES STORE ELECTRICITY EVEN AFTER THE
  POWER HAS BEEN DEACTIVATED AT THE POWER BREAKER. Wait for 2 minutes after the shut down
  of equipment before servicing.
- Deactivate power while routing wiring to control board.
- Follow all National Electric Codes (NEC) and/or State and Local guidelines.

# **MWARNING**

Failure to heed the following may result in injury or death.

- This section is only for qualified installers who are familiar with the swimming pool and spa safety standards.
- The installer must be familiar with service industry techniques.

## **NOTICE**


Failure to heed the following may result in damage to equipment.

- The wire size connecting the relay switch must be a minimum 22-gauge, 2-conductor, low-voltage wire.
- Use FS2 (dry contact) connection on the microprocessor.


### **Connecting Switch**


- 1. Deactivate power to heat pump.
- 2. Plumb the switch as indicated in accessories installation instructions.
- 3. Remove heat pump electrical access panel.
- 4. Using two of the three wires from the installed switch, route wires to the low voltage side of the electrical enclosure. The third wire is not used. Follow all National Electric Codes (NEC) unless State or Local guidelines supersede.
- 5. Connect the wires to the jumper provided. Polarity is not important.
- 6. Reattach heat pump access panel.
- 7. Apply power to heat pump.
- 8. Configure the heat pump to accept the pool/spa relay switch. See "*Configuring Switch*" below.

# Dry Contact Connection Points to the Microprocessor





### **Configuring Switch**






























## 1.7 Program Heat Pump for the Customer


## 1.7.a Setting Date and Time


Set the heat pump's time and date using the following steps.


















## 1.7.b Setting Time and Date Format

The heat pump's time and date format can be customized.

## Customize Time


The time can be displayed in 24-hour military time (the default display is 12 hour).



































### Customize Date


The date can be displayed as Day-Month-Year (the default is Month-Day-Year).




































## 1.7.c Selecting Celsius or Fahrenheit


Set the water temperature to show in either Fahrenheit (default) or Celsius.














### 1.7.d Configure Variable Speed Compressors

Selected heat pumps have variable speed compressors designed to more quickly and efficiently reach a temperature set point. The compressor's performance can be controlled using a turbo boost mode or two different types of efficiency modes.

#### **Turbo Boost**

Upon demand, the heat pump's compressor can be set to maximum speed to heat or cool the water quickly. This is regardless of any previously set efficiency mode settings.

• The system will heat or cool the water with the compressor speed set to maximum. This will continue until the set temperature is reached. Then the configured efficiency mode (scheduled or 24-hour) will resume.

### Efficiency Mode - 24 Hour

When using this mode, the compressor is set to its maximum speed until the temperature set point is reached.

- The compressor speed will then lower to maintain that temperature set point. This will continue as long as there is water flow.
- See "Set Efficiency Mode to 24 Hour" on page 55.

#### **Efficiency Mode - Filtration Schedule**


When using this mode, the compressor's speed is set to heat or cool the water within 60% of the circulation pump's filtration time period. This is the highest efficiency operational mode, providing the lowest cost of operation.

• Example - If the filtration period is set from 10:00 am to 8:00 pm, the system attempts to bring the water to set point by 4:00 pm at optimal performance.

#### **PLEASE NOTE:**


Setting a filtration schedule outside the current circulation pump's schedule will cause an incorrect efficiency mode.


• See "Set Efficiency Mode to Filtration Schedule" on page 56.




















## **Set Efficiency Mode to 24 Hour**

























































## 1.7.e Setting Entry Code Option

The entry code feature can prevent unauthorized temperature adjustments. This feature initiates after the heat pump goes into the sleep mode for the first time.


## **NOTICE**


Failure to heed the following may result in damage to equipment.


• **Before enabling the entry code feature, be sure to record the code.** If lost, the heat pump will require a program reset to regain access. This reset may require additional configuration by the installer.



















Page - 58













## 1.7.f Using Entry Code to Access Heat Pump

If a user entry code has been enabled in the user menu, an entry code will be required to access heat pump options.





### PLEASE NOTE -

- If the entry code has been misplaced, the heat pump will need to be reset to factory defaults.
- After three minutes of inactivity, the heat pump's sleep mode will activate.


## 1.7.g Resetting Factory Defaults


If needed, the installer can reset programming to the heat pump's factory default settings. See "Factory Defaults" on page 78.

### PLEASE NOTE:

This will reset any external device configurations.


## Enter "Installer Menus", then proceed








Page - 60






















## 1.8 Cleaning Equipment After Installation

Installer - If you need to clean the equipment after installation, please use the following guidelines.



Failure to heed the following may result in injury or death.

• Possible electric shock hazard - Deactivate power to all electrical devices on the pad when washing heat pump. Do not restore electrical power until equipment is completely dry.

## **NOTICE**

Failure to heed the following may result in damage to equipment.

- Do not use a pressure cleaner to wash the heat pump. Damage to heat pump components may result. If using a hose-end spray nozzle adjust the spray pattern to low strength only.
- Do not spray water directly into the interior of the heat pump; damage to components may result.
- Do not use chemicals on the display panel.

#### Cleaning

- 1. Wash cabinet using a <u>low-pressure</u> water hose. A high-pressure water stream will cause damage to the aluminum fins of the heat pump. This damage is not covered under the product warranty.
- 2. While the heat pump is still wet, use an approved cleaning agent to clean the exterior of the heat pump. **Do not use chemicals on the display panel.**
- 3. Use a detergent-dampened cloth to wipe the heat pump's exterior cabinet.
- 4. Flush all exterior with fresh water using a low-pressure water hose.
- 5. Dry the cabinet using a soft cloth being careful not to damage fins.

APPROVED CLEANING AGENTS
Fantastic®
Formula 409®
Cascade <sup>®</sup>
All Power Plain Detergent (3% Solution)

Table 3 - Cleaning Agents

• The trademarks used in approved cleaning agents are the property of their owners and are not related to AquaCal\*.

## **Polishing**

- 1. Polish the heat pump's cabinet panels using an approved polishing agent and following the manufacturer's instructions. **Do not use chemicals on the display panel.**
- 2. Rinse the heat pump panels with fresh water, wipe, and buff panels using a dry soft cloth.
- 3. Allow heat pump interior and surrounding equipment to "air-dry" for several hours prior to restoring electrical power.

APPROVED POLISHING AGENTS*
Simoniz® Wax
Glo-Coat®
Armor All® Protectant

Table 4 - Polishing Agents

<sup>•</sup> The trademarks used in approved polishing agents are the property of their owners and are not related to AquaCal\*.

## 2 - Troubleshooting

IN THIS SECTION:	
Fault Codes	
AIR TEMP SENSOR OPEN or AIR TEMP SENSOR SHORT	65
CLOCK LOW BATTERY	65
DEFROST1 SENSOR OPEN or DEFROST2 SENSOR OPEN	66
DEFROST1 SENSOR SHORT or DEFROST2 SENSOR SHORT	66
ERROR AT PRIMARY UNIT	66
HIGH PRESSURE FAULT	67
HIGH WATER TEMPERATURE	68
HP5 SYSTEM LOCKOUT	68
LOW PRESSURE FAULT	69
LP5 SYSTEM LOCKOUT	69
MULTI-UNIT COMM FAULT	70
OTA SYSTEM LOCKOUT	70
SMART COMM FAULT	70
VARIABLE DRIVE FAULT	70
WATER TEMP SENSOR SHORT or WATER TEMP SENSOR OPEN	70
Issues and resolutions	
Blank Display	71
Display Panel Not Responding	71
Displays "DEFROSTING"	72
Displays "NO SYSTEM FIRMWARE"	72
Displays "NO POOL/SPA WATER FLOW"	72
Displays "SET TO SWITCH REMOTELY"	73
Displays "SET UNIT MODEL NUMBER"	73
Heat Pump Not Running	73
Heat Pump's Tripping Breaker	73
Heat Pump Won't Shut Off	74
Heat Pump Is Running, Not Heating	74
Heat Pump Is Running, Not Cooling	75
Ice Forming on the Heat Pump	76
"Pool / Spa" Button Will Not Work	76
Water Coming From Heat Pump	77

#### 2.1 Fault Codes

A fault code indicates a specific issue or condition that will require action before the equipment can resume operating.

Please perform the following troubleshooting.

If the issue reoccurs, please contact AquaCal. See "Contacting AquaCal AutoPilot, Inc." on page 1.

# **A**DANGER

Failure to heed the following will result in injury or death.

- RISK OF ELECTRICAL SHOCK FROM ENERGY STORED IN CAPACITORS MODELS EQUIPPED WITH VARIABLE FREQUENCY COMPRESSOR DRIVES STORE ELECTRICITY EVEN AFTER THE POWER HAS BEEN DEACTIVATED AT THE POWER BREAKER. Wait for 2 minutes after the shut down of equipment before servicing.
- Deactivate power while routing wiring to control board.
- Follow all National Electric Codes (NEC) and/or State and Local guidelines.

## **AWARNING**

Failure to heed the following may result in injury or death.

- Repairs must not be attempted by untrained or unqualified individuals.
- The heat pump contains refrigerant under high pressure. Repairs to the refrigerant circuit must not be attempted by untrained or unqualified individuals. Service must be performed only by qualified HVAC technicians. Recover refrigerant before opening the system.

## **NOTICE**

Failure to heed the following may result in damage to equipment.

• Service by unauthorized personnel will void the heat pump warranty.

### AIR TEMP SENSOR OPEN or AIR TEMP SENSOR SHORT

#### **ISSUE**

Open or shorted air sensor.

#### RESOLUTION

A qualified technician should replace the air sensor.

### **CLOCK LOW BATTERY**

#### **ISSUE**

The real-time clock controller indicates a low battery condition.

- The time will reset to factory default.
- If connected, a gas backup heater may start and stop at an incorrect time when set to use a "SCHEDULED" mode.

#### RESOLUTION

A qualified technician should replace the battery. The date and time will need to be reset on the heat pump after replacement.

## DEFROST1 SENSOR OPEN or DEFROST2 SENSOR OPEN

## **ISSUE**

Open defrost sensor.

## RESOLUTION

A qualified technician should replace the defrost sensor.

## DEFROST1 SENSOR SHORT or DEFROST2 SENSOR SHORT

## **ISSUE**

Shorted defrost sensor.

## RESOLUTION

A qualified technician should replace the defrost sensor.

## **ERROR AT PRIMARY UNIT**

### **ISSUE**

The heat pump is secondary to a primary heat pump that is displaying a fault code.

## RESOLUTION

The error at the primary heat pump must be corrected before the secondary unit will resume operation.

#### **HIGH PRESSURE FAULT**

#### **ISSUE**

The refrigerant system's high-pressure switch is showing as open.

#### RESOLUTION

## **Heat Only Units**

Place heat pump in heating mode and perform the following troubleshooting.

Determine if an insufficient amount of water is being supplied to the equipment.

- 1. Confirm the filter pump is on.
- 2. If a multiple-speed filter pump is being used, run filter pump at a higher speed. Do not exceed the maximum flow rate for the model.
- 3. Confirm water is not being diverted away from the heat pump.
  - See "Water Flow Rates" on page 11.
  - See "Adjusting Water Flow Using △T (Delta-T)" on page 12.
- 4. The water pressure switch may be incorrectly calibrated.
  - See "Adjusting Water Pressure Switch" on page 15.

## **Cool Only Units**

Determine if an insufficient amount of air is being supplied to the equipment.

- 1. Check for proper fan operation. If the fan is not operating, contact AquaCal\* Technical Support.
- 2. Check for obstructed airflow around the heat pump.
  - See "Clearances" on page 5.
- 3. Check for a dirty or blocked evaporator coil.
  - See "Cleaning Equipment After Installation" on page 62.

### **Heat and Cool Units (Reversing)**

Place heat pump in heating mode and perform the following troubleshooting.

Determine if an insufficient amount of water is being supplied to the equipment.

- 1. Confirm the filter pump is on.
- 2. If a multiple-speed filter pump is being used, run filter pump at a higher speed. Do not exceed the maximum flow rate for the model.
- 3. Confirm water is not being diverted away from the heat pump.
  - See "Water Flow Rates" on page 11.
  - See "Adjusting Water Flow Using  $\Delta T$  (Delta-T)" on page 12.
- 4. The water pressure switch may be incorrectly calibrated.
  - See "Adjusting Water Pressure Switch" on page 15.

#### **HIGH WATER TEMPERATURE**

#### **ISSUE**

Incoming water temperature has exceeded 110° F (43° C) and the unit has been deactivated. The heat pump will not operate until the incoming water temperature drops to 100° F (38° C) or lower.

#### RESOLUTION

- 1. Determine if a gas heater is sending water directly to the heat pump. This situation would need to be corrected before continuing.
- 2. If a solar heater is sending water directly to the heat pump, the water can initially be hotter than 110° F (43° C). After the water from the solar panel normalizes, the fault will no longer display and the heat pump will resume as needed.
- 3. If the **HIGH WATER TEMPERATURE** fault continues to display, the water temperature sensor may require replacement.

#### **HP5 SYSTEM LOCKOUT**

#### **ISSUE**

The heat pump has locked due to five high-pressure faults during one call for heating or cooling.

#### RESOLUTION

- 1. Deactivate then reactivate power to the heat pump to clear error.
- 2. Troubleshoot the high-pressure issue causing the error.
  - See "HIGH PRESSURE FAULT" on the previous page.

### **LOW PRESSURE FAULT**

### **ISSUE**

The refrigerant system's low-pressure switch is showing as open.

### RESOLUTION

# **Heat Only Units**

Place heat pump in heating mode and perform the following troubleshooting.

- 1. Check for proper fan operation. If the fan is not operating, contact AquaCal® Technical Support.
- 2. Check for obstructed airflow around the heat pump.
  - See "Clearances" on page 5.
- 3. Check for a dirty or blocked evaporator coil.
  - See "Cleaning Equipment After Installation" on page 62.
- 4. Check for signs of heavy ice buildup on the coil.

## **Cool Only Units**

Place heat pump in heating mode and perform the following troubleshooting.

Determine if an insufficient amount of water is being supplied to the equipment.

- 1. Confirm the filter pump is on.
- 2. If a multiple-speed filter pump is being used, run filter pump at a higher speed. Do not exceed the maximum flow rate for the model.
- 3. Confirm water is not being diverted away from the heat pump.
  - See "Water Flow Rates" on page 11.
  - See "Adjusting Water Flow Using △T (Delta-T)" on page 12.
- 4. The water pressure switch may be incorrectly calibrated.
  - See "Adjusting Water Pressure Switch" on page 15.

# **Heat and Cool Units (Reversing)**

Place heat pump in heating mode and perform the following troubleshooting.

- 1. Check for proper fan operation. If the fan is not operating, contact AquaCal\* Technical Support.
- 2. Check for obstructed airflow around the heat pump.
  - See "Clearances" on page 5.
- 3. Check for a dirty or blocked evaporator coil.
  - See "Cleaning Equipment After Installation" on page 62.
- 4. Check for signs of heavy ice buildup on the coil.

### **LP5 SYSTEM LOCKOUT**

### **ISSUE**

The heat pump has locked due to five low-pressure faults during one call for heating or cooling.

- 1. Deactivate then reactivate power to the heat pump to clear error.
- 2. Troubleshoot the low-pressure issue causing the error.
  - See "LOW PRESSURE FAULT" above.

### **MULTI-UNIT COMM FAULT**

### **ISSUE**

Secondary heat pump is not receiving a signal from the primary heat pump.

### RESOLUTION

- 1. Confirm the primary heat pump is operating correctly. If, for example, no power is supplied to the primary heat pump, an error will appear on the secondary heat pumps.
- 2. Confirm the heat pump is properly connected and configured to a primary unit.
  - See "Connecting Multiple Heat Pumps (Primary / Secondary)" on page 39.

### **OTA SYSTEM LOCKOUT**

### **ISSUE**

A malfunction has occurred that could allow the water temperature to surpass a safe level. An installed "Over Temperature Alarm" kit has disabled the system.

• See "Over Temperature Alarm Kit" on page 83 for more information.

## RESOLUTION

Call for service.

### **SMART COMM FAULT**

### **ISSUE**

Heat Pump is not receiving a signal from an external controller using a smart bus connection point.

### RESOLUTION

- 1. Confirm a smart bus external controller is being used.
  - If not, set external controller mode to "none" instead of "SMART".
    - See "Configure for Smart Bus Controller" on page 29.
- 2. Confirm connection points from the external controller to the heat pump are correctly configured.
  - See "Connecting Smart Bus Controllers" on page 27.
- 3. If using a smart bus external controller, confirm the controller is correctly set to send signals to the heat pump. See manuals or guides provided with the external controller.

### **VARIABLE DRIVE FAULT**

### **ISSUE**

A problem was detected in the variable speed compressor.

### RESOLUTION

Deactivate heat pump at power disconnect. Wait for two minutes for the capacitors to discharge.

Then reactivate heat pump's power at disconnect. If error reoccurs, call for service.

### WATER TEMP SENSOR SHORT or WATER TEMP SENSOR OPEN

### **ISSUE**

Shorted or open water sensor.

### RESOLUTION

A qualified technician should replace the water sensor.

### 2.2 Issues and Resolutions



Failure to heed the following will result in injury or death.

- RISK OF ELECTRICAL SHOCK FROM ENERGY STORED IN CAPACITORS MODELS EQUIPPED WITH VARIABLE FREQUENCY COMPRESSOR DRIVES STORE ELECTRICITY EVEN AFTER THE POWER HAS BEEN DEACTIVATED AT THE POWER BREAKER. Wait for 2 minutes after the shut down of equipment before servicing.
- Deactivate power while routing wiring to control board.
- Follow all National Electric Codes (NEC) and/or State and Local guidelines.

# **AWARNING**

Failure to heed the following may result in injury or death.

- Repairs must not be attempted by untrained or unqualified individuals.
- The heat pump contains refrigerant under pressure. Repairs to the refrigerant circuit must not be attempted by untrained or unqualified individuals. Service must be performed only by qualified HVAC technicians. Recover refrigerant before opening the system.

# **NOTICE**

Failure to heed the following may result in damage to equipment.

• Service by unauthorized personnel will void the factory warranty.

Please perform the following troubleshooting.

For further assistance, please contact AquaCal. See "Contacting AquaCal AutoPilot, Inc." on page 1.

# **Blank Display**

#### **ISSUE**

The Heat Pump may have an incoming power problem.

### RESOLUTION

Confirm electrical power is being supplied to the heat pump from electrical disconnect(s).

## **Display Panel Not Responding**

### **ISSUE**

The heat pump's display panel will not respond to user input.

- 1. If heat pump display shows "UNDER REMOTE CONTROL", use the external control device to control the heat pump.
- 2. If needed, check with the external controller manufacturer for further assistance using that device.

# **Displays "DEFROSTING"**

### **ISSUE**

The heat pump has sensed the coil is icing up. See "*Ice Forming on the Heat Pump*" on page 76. No action is required.

### RESOLUTION

# **Heat Only Units - Passive Defrost**

When ice starts to form on the coil, the compressor will stop operating while the fan continues to operate.

- The coil will begin to warm to the surrounding air temperature. When the coil's temperature rises above 38° F (3.3° C), the compressor is restarted and heating resumes.
- If the coil's temperature remains below 38° F (3.3° C), the compressor will remain off.

## **Cool Only Units - Passive Defrost**

When ice starts to form on the coil, the compressor will stop operating while the fan continues to operate.

- The coil will begin to warm to the surrounding air temperature. When the coil's temperature rises above 38° F (3.3° C), the compressor is restarted and cooling resumes.
- If the coil's temperature remains below 38° F (3.3° C), the compressor will remain off.

### **Heat and Cool Units - Active Defrost**

Hot refrigerant gas will be sent through the coil to rapidly remove ice or frost.

During this process, the melting of the ice may appear as steam coming off the heat pump. This is normal.

# **Displays "NO SYSTEM FIRMWARE"**

### **ISSUE**

The heat pump has encountered a software error.

### RESOLUTION

Call for service.

## Displays "NO POOL/SPA WATER FLOW"

#### **ISSUE**

Low or no water detected. This is normal when the circulation pump is deactivated.

- 1. Confirm the filter pump is on.
- 2. If a multiple-speed filter pump is being used, run at a higher speed to determine if the error persists. Do not exceed the maximum flow rate for your model.
- 3. Confirm water is not being diverted away from the heat pump.
  - See "Water Flow Rates" on page 11.
  - See "Adjusting Water Flow Using  $\Delta T$  (Delta-T)" on page 12.

# **Displays "SET TO SWITCH REMOTELY"**

### **ISSUE**

If when pressing the "Pool / Spa" button the display flashes the message "**SET TO SWITCH REMOTELY**", the heat pump is using a remote relay switch or a 3-wire controller.

### RESOLUTION

- The Pool and Spa thermostat automatically switch when using these modes.
- Operation manually will not be available when using these external devices. No action is required.

### Displays "SET UNIT MODEL NUMBER"

### **ISSUE**

The heat pump has encountered a software error.

### RESOLUTION

- The model number and serial number will need to be re-entered into the system. The system will then operate as normal.
- If the issue reoccurs, please contact AquaCal\* Technical Support.

# **Heat Pump Not Running**

#### ISSUE

The heat pump will not run.

### RESOLUTION

- 1. Confirm equipment is receiving power. Is the heat pump display illuminated?
  - If not, confirm the main breaker (located at the power supply panel) and the disconnect switch (located near the heat pump) are both turned on.
  - If the display still does not illuminate, it is recommended that the heat pump installer or electrician confirm the heat pump is receiving power.
- 2. Confirm correct mode is selected.
- 3. Confirm thermostat is set correctly.
  - When heating the water is desired, the thermostat should be set above the current water temperature.
  - When cooling the water is desired, the thermostat should be set below the current water temperature.
- 4. If an error code is displayed, diagnose and correct the cause of the code.
  - See "Fault Codes" on page 65.
- 5. If the heat pump is using an external controller, the heat pump may not be set correctly to accept the controller's signal.

# **Heat Pump's Tripping Breaker**

#### ISSUE

The heat pump breaker(s) keeps tripping.

- 1. If AquaCal heat pumps have been connected using a multiple heat pump configuration, the configuration may be incorrect. Please confirm settings or contact installer of equipment.
  - See "Connecting Multiple Heat Pumps (Primary / Secondary)" on page 39.
- 2. Have an electrician confirm breakers are correct type, in good condition, and properly sized for the heat pump.

# Heat Pump Won't Shut Off

## **ISSUE**

The heat pump will not deactivate.

### RESOLUTION

### PLEASE NOTE

When the heat pump is set to off, the display will show the current water temperature or no water flow indicator.

- 1. Confirm the correct mode has been set on the heat pump.
- 2. Confirm the heat pump has reached the desired temperature set on the thermostat. The heat pump will continue to run until the set temperature is reached.
- 3. If the heat pump is using an external controller, it may not be set correctly. See the external controller's manual.

# **Heat Pump Is Running, Not Heating**

### **ISSUE**

The heat pump is running. But the water is not heating.

- 1. If the heat pump is using an external controller, confirm it is set correctly.
  - See operation manual for operating heat pump with an external controller.
  - If the heat pump is still not running correctly with this device, contact the installer of the device or the device's manufacturer for further assistance.
- 2. Confirm heat pump mode is set to heat.
- 3. Confirm thermostat is set to the desired water temperature.
- 4. Confirm valves are positioned to heat the correct body of water (either the pool or the spa). If heating a spa that overflows into a pool, confirm the spa is isolated when being heated (not flowing into the pool).
- 5. Confirm heat pump is transferring heat into the water.
  - Measure the temperature of air discharge coming out of the heat pump fan. If discharge air is between 8° to 10° F (4.4° to 5.6° C) colder than the outside ambient air, the heat pump is moving heat into the water.
- 6. If an error code is displayed, diagnose and correct cause of code.
  - See "Fault Codes" on page 65.
- 7. Confirm that the filter pump has a sufficient run-time. The heat pump will not run (or heat the water) without water flow.
  - See "Heating Recommendations" on page 82.
- 8. If heating a spa, deactivate air blower or venturi (if equipped) to allow for quicker heating times. For pools, deactivate water features, such as slides, waterfalls, or fountains to allow water to retain heat. Use of a liquid pool blanket product, such as an Aqua Blanket™, can also compensate for excessive heat loss.
  - See "Liquid Blankets" on page 83.

# **Heat Pump Is Running, Not Cooling**

# **ISSUE**

The heat pump is running. But the water is not cooling.

- 1. If the heat pump is using an external controller, confirm the heat pump is programmed properly to allow for cooling.
- 2. Confirm the heat pump mode is set to cool.
- 3. Confirm the thermostat is set below the current water temperature.
- 4. Confirm valves are positioned to cool the correct body of water (either the pool or the spa). If cooling a spa that overflows into a pool, confirm the spa is isolated when being cooled (not flowing into the pool).
- 5. If an error code is displayed, determine and correct the condition causing the code.
  - See "Fault Codes" on page 65.
- 6. Confirm heat pump is transferring heat out of the water.
  - Measure the temperature of air discharge coming out of the heat pump's fan. If the air is between 8° to 10° F (4.4° to 5.6° C) warmer than the outside ambient air, the heat pump is moving heat out of the water.
- 7. Confirm that the filter pump has a sufficient run-time. The heat pump will not run (or cool the water) without water flow.

# Ice Forming on the Heat Pump

### **ISSUE**

When conditions are too cold for proper operation, the heat pump will enter a defrost mode. This prevents ice from building up on the evaporator coil.

### RESOLUTION

# **Heat Only Units:**

- The heat pump may develop a fine layer of white frost on the outside coil before entering the defrost mode. This is normal.
  - See "Displays Defrosting" on page 72.
- If heavy ice (not frost) starts to build up, shut off the heat pump. Contact the installer or manufacturer.
- If the ambient air temperature will be falling below 32° F (0° C) for more than 8 hours, winterize equipment.

# **Cool Only Units**

- The heat pump may enter defrost mode if the water flow rate falls below the acceptable range. See "Water Flow Rates" on page 11.
- If the ambient air temperature will be falling below 32° F (0° C) for more than 8 hours, winterize equipment.

# Heat and Cool Units (with Active Defrost or "Icebreaker"):

- During freezing conditions, pool or spa heating will continue. Frost or ice may develop during the "countdown" to the active defrost (up to 50 minutes). This is normal. See "Displays Defrosting" on page 72.
- The heat pump will enter an "active defrost" stage to remove the accumulated frost and ice.
  - Be sure to observe the unit for at least 50 minutes. If it has not entered an active defrost cycle, call for service.

## TIP:

The heat pump can be manually set to defrost by temporarily switching to the cooling mode until the ice or frost melts.

• If the ambient air temperature is (or will be) falling below 32° F (0° C) for more than 8 hours, winterize equipment.

# "Pool / Spa" Button Will Not Work

#### ISSUE

The "Pool / Spa" button is disabled if the following devices have been configured on the heat pump.

- A 2-wire external controller.
- A 3-wire external controller.
- An external flow switch.

# **Water Coming From Heat Pump**

# **ISSUE**

The water may be normal condensation produced as a by-product of the heat pump's refrigeration process.

The heat pump can produce up to 8 to 10 gallons (30 to 38 liters) of condensation per hour depending on the humidity of the ambient air. Determine if the water is condensation or a possible leak.

## RESOLUTION

- 1. Deactivate heat pump, leaving the filter pump on. After several hours, determine if the water is still coming from the heat pump.
- 2. If using chlorine or bromine as a pool/spa sanitizer, test the water around the heat pump using a test strip. If the test strip indicates that chlorine or bromine is present, a leak may exist.

## PLEASE NOTE -

If desired, a kit is available to re-direct condensation water away from the heat pump.

• See "Condensation Drain Kit (#STK0202)" on page 82.

# 3 - Appendix

IN THIS SECTION:	
3.1 Factory Defaults	78
3.2 Identifying Model Specifications	79
3.3 Weights	81
3.4 Heating Recommendations	82
3.5 Cooling Recommendations	82
3.6 Available Accessories	82

# 3.1 Factory Defaults

Certain programming options have been preset at the factory. These options can be overwritten for site-specific conditions.

# **NOTICE**

Failure to heed the following may result in damage to equipment.

• Unauthorized adjustments in Service Menus (not shown) may void the heat pump's warranty.


User Menus			
MENUS	DEFAULT	OPTIONS	
SET GAS BOOST	OFF	OFF	
SET GAS BOOST	UFF	ON	
SET TIME / DATE	USER TO SET		
		OFF	
SET BACKUP HEAT MODE	OFF	SCHEDULED	
		24HR	
SET ENTRY CODE ENABLED	OFF	OFF	
SET ENTRY CODE ENABLED	Off	ON	
SET USER ENTRY CODE	01		
		OFF	
SET CALL-FLEX MODE	OFF	CALL	
		FLEX	

Installer Menus			
MENUS	DEFAULT	OPTIONS	
		OFF	
SET MULTI-UNIT MODE	OFF	PRIMARY	
		SECONDARY	
		OFF	
SET EXT. CTRL MODE	OFF	SMART	
		2WIRE	
		3WIRE	

Installer Menus			
MENUS	DEFAULT	OPTIONS	
SET TIME FORMAT	12 Hour	12 Hour	
	12 nour	24 Hour	
SET DATE FORMAT	MDY	MDY	
SET DATE FORMAT	WID I	DMY	
SET TEMPERATURE UNITS	Fahrenheit	Fahrenheit	
	Tamemen	Celsius	
SET BACKUP HEAT MODE		OFF	
	OFF	SCHEDULED	
		24HR	
SET ENTRY CODE ENABLED	OFF	OFF	
	OFF	ON	
SET USER ENTRY CODE	01		
SET CALL-FLEX INSTALLED	NO	YES	
	NO	NO	
SET CALL-FLEX MODE		OFF	
	OFF	CALL	
		FLEX	

# 3.2 Identifying Model Specifications

- 1. Find Data Plate The data plate is usually posted on the side of the equipment or the inside of the heat pump's access plate.
- 2. Find the model number on the data plate. The first letters and numbers indicate the model type.
- 3. The complete model number identifies the equipment's specifications.



#### **Model Number Example** MODEL NUMBER NOMENCLATURE B N N Brand Designation Unit Revision A THROUGH Z AA THROUGH ZZ AAA THROUGH ZZZ Unit Designation Water Coil Designation Voltage Designation (Voltage / Hertz / Phase) C = Cupronickel D = Demo Unit A = 208-230/60/1 H = High Pressure Cupronickel $\mathbf{B} = 208\text{-}230/60/3$ L = Tube-in-tubeD = 380-415/50/3 M = Packaging for Mexico E = 380-420/60/3 N = No OptionsG = 460/60/3P = ThermoLink® II (5/8 for 2016) H = 200-220/50/1 R = ThermoLink® II (3/4 and 5/8) N = Ni1 $T = ThermoLink_{\circledR} II$ X = None Features C = Chill Only H = Heat Only R = Heat and Cool S = Split Chiller Color Designation A = Black outside cabinet / White inside cabinet T = Split Heater B = Black Controls W = WhiteD = Digital A = Analog N = None V = Variable Speed Compressor C = Creme T = Taupe Refrigerant S = R410A T = R407C E = R22 UPDATED 07/14/2016

# 3.3 Weights

# NOTE:

Specifications subject to change.

Model Type	Model Number	Install Weight		
TropiCal <sup>®</sup>	T025	180 Pounds		
	T035	(81.6 kg)		
TropiCal <sup>®</sup>	T055	180 Pounds		
	T055	(81.6 kg)		
TropiCal <sup>®</sup>	T075	200 Pounds		
	10/3	(90.7 kg)		
TropiCal <sup>®</sup>	T090	255 Pounds		
	1090	(115.7 kg)		
TropiCal <sup>®</sup>	T115	259 Pounds		
	1113	(117.5 kg)		
TropiCal <sup>®</sup>	T135	287 Pounds		
	1133	(130 kg)		
TropiCal <sup>®</sup>	T170	326 Pounds		
	11/0	(148 kg)		
HeatWave SuperQuiet®	SQ120R	268 Pounds		
	5Q120K	(121.6 kg)		
HeatWave SuperQuiet®	SQ125	268 Pounds		
	5Q123	(121.6 kg)		
HeatWave SuperQuiet®	SQ145	328 Pounds		
	5Q143	(148.8 kg)		
HeatWave SuperQuiet®	SQ150VS	350 Pounds		
	5Q13075	(158.8 kg)		
HeatWave SuperQuiet®	SQ166R	328 Pounds		
	5Q100K	(148.8 kg)		
HeatWave SuperQuiet®	SQ225	328 Pounds		
	5Q223	(148.8 kg)		
TropiCool <sup>®</sup>	TC500	215 Pounds		
	10300	(97.5 kg)		
TropiCool <sup>®</sup>	TC1000	285 Pounds		
	101000	(128.8 kg)		
TropiCool <sup>®</sup>	TC1500	328 Pounds		
	101300	(148.8 kg)		

# 3.4 Heating Recommendations

The following recommendations will reduce the amount of time required to heat a pool. **If unsure of equipment heating capability, review equipment data plate.** See "*Identifying Model Specifications*" on page 79.

- 1. Confirm heat pump mode has been set to heating mode.
- 2. Set the desired temperature (set-point) for the water.
- 3. Temporarily set the filter pump for continuous operation.
  - This will allow the Heat Pump the time required to heat the water at start-up.
  - After the water has reached the desired temperature, reset the filter pump to normal operating time-frames.
- 4. Activate Turbo Boost Mode if equipped.
- 5. Use a pool cover or blanket to reduce heating time.

# 3.5 Cooling Recommendations

The following recommendations will reduce the amount of time required to cool a pool or cold plunge application. **If unsure of equipment cooling capability, review equipment data plate.** See "*Identifying Model Specifications*" on page 79.

- 1. Confirm heat pump mode has been set to cooling mode.
- 2. Set thermostat to desired water temperature.
- 3. Activate Turbo Boost Mode if equipped.
- 4. Temporarily set the filter pump for continuous operation.
  - This will allow the Heat Pump the time required to cool the water at start-up.
  - After the water has reached the desired temperature, reset the filter pump to normal operating time-frames.

# 3.6 Available Accessories

Accessories may be purchased through an authorized dealer of AquaCal® products.

### **Bypass Valve Kit (# STK0135)**

- When high flow rates are outside recommended specifications, please use this kit or an alternative bypass valve system.
- This kit can be used to control excessive water flow through the heat pump. It provides automatic flow adjustments for most applications.



# Condensation Drain Kit (# STK0202)

 Used when condensation water flow must be directed to a specific location.



## Call Flex Accessory (# 0030-LEDS)

• This accessory will override a circulation pump to provide water to the heat pump when the set temperature is not met.



### Grid Flow Switch (# 0040S)

- Used for automatic pool/spa thermostat switching.
- This switch can also be used in place of the water pressure switch. This may be needed when the pool/spa elevation is higher than the heat pump. A higher elevation of the water can cause a false signal to the heat pump; indicating water is flowing through the heat pump when it isn't.
- This kit is not to be used on applications exceeding 50 PSI (345 kPa).



### **Liquid Blankets**

- An invisible liquid heat barrier designed to retain heat and extend the swimming season.
- AquaCal® recommends Lo-Chlor® Aqua Blanket™.



### **Over Temperature Alarm Kit**

- This kit is an additional safety device. It disables the heat pump if <u>any</u> malfunction occurs that allows the water temperature to surpass a safe level.
- This kit is strongly recommended for all spa applications.
  - Single Phase Heat Pump (# STK0221)
  - Three Phase Heat Pump (# STK0222)



# **Plumbing Unions**

• 2 Inch Unions - (# PLS2627)



# **Temperature Port Kit (# STK0096)**

- This kit can be used to adjust water flow using Delta-T.
- The kit comes with a port, installation components, and a temperature probe.

