


SolarPRO™ CURVE HEATER OWNER'S MANUAL

ENGLISH

MODEL 4721

IMPORTANT SAFETY RULES

Read all instructions BEFORE assembling and using
this product. KEEP THIS MANUAL.



IMPORTANT DO NOT RETURN PRODUCT TO STORE

For technical assistance and missing parts, call Customer Service toll-free

1.888.339.2546

(press 135 at any time)

Monday through Thursday, 8:00 am to 5:00 pm MST

Friday, 8:00 am to 2:00 pm MST

Please visit our website, www.game-group.com, for potential updates to these instructions.



IMPORTANT

**Approved for use with any filter pump up to a maximum of 1.5 HP.
Use of any other type of pump will void the warranty.**

**For filter pumps greater than 1.5 HP,
a GAME Bypass Kit is required (sold separately).**

CONNECTING MULTIPLE UNITS

**DO NOT install multiple units directly into the return line.
Doing so may damage the product and will void the warranty.**

**To install multiple units, you MUST use a GAME Bypass Kit,
available from your local swimming pool specialty retailer.
Contact GAME to receive a list of retail sources in your area.**

**If you wish further information regarding the installation
of multiple heaters, please contact GAME Customer Service
(1.888.339.2546 ext 135) or see your local swimming pool specialist.**

**YOUR POOL HEATER HAS BEEN ENGINEERED AND MANUFACTURED
TO OUR HIGHEST STANDARD FOR DEPENDABILITY, EASE OF OPERATION
AND SAFETY. THANK YOU FOR YOUR PURCHASE.**

TABLE OF CONTENTS

1. Safety Warnings	4
2. General Information	4
3. Parts List/Reference	5
4. Installation Instructions	6
5. Initial Operation	8
6. Maintenance	8
7. Troubleshooting	8
8. Warranty	9
9. Appendix: Exploded Parts Diagram	10

**READ ALL INSTRUCTIONS BEFORE ASSEMBLING AND USING
THIS PRODUCT. FAILURE TO FOLLOW INSTRUCTIONS CAN CAUSE
SEVERE AND/OR FATAL INJURY.**

**IMPORTANT
DO NOT RETURN PRODUCT TO STORE**

For technical assistance and missing parts, call Customer Service toll-free

1.888.339.2546

(press 135 at any time)

Monday through Thursday, 8:00 am to 5:00 pm MST

Friday, 8:00 am to 2:00 pm MST

Please visit our website, www.game-group.com, for potential updates to these instructions.

1. SAFETY WARNINGS

READ ALL WARNINGS BELOW. FAILURE TO DO SO COULD RESULT IN SERIOUS PERSONAL INJURY OR DEATH.

- Carefully read and adhere to all CAUTION and NOTE notices located throughout this manual. Failure to comply with these instructions can cause serious injury, death, or damage to the unit.
- Do NOT allow children to operate this product.
- Always turn the filter system to a setting that does not allow flow to the pool return when installing or working on the solar heater.
- Install product away from the pool to prevent children from using the heater as a way to access the pool.
- NEVER service this unit with the pool pump running.
- Do not use any petroleum based lubricant. Petroleum based products will destroy plastic parts.

THESE CAUTION WARNINGS ARE NOT INTENDED TO INCORPORATE ALL POSSIBLE INSTANCES FOR RISK AND/OR SEVERE INJURY. THE POOL OWNER SHOULD ALWAYS EXERCISE CAUTION AND COMMON SENSE WHEN UTILIZING THEIR SWIMMING POOL AND OPERATING EQUIPMENT.

2. GENERAL INFORMATION

This manual provides information relating to the installation, utilization and maintenance of our solar heater. We recommend you read this manual in its entirety and keep it for future reference.

The solar heater you just purchased for your above ground pool is simple to install and effortless to operate once connected. The installation instructions included in this manual are based on a few assumptions: 1) you have an existing above ground pool that is completely set up and filled with water, 2) your above ground pool is equipped with a pump-operated water filtering system, and 3) you have the necessary hoses needed to feed water in and out of your pool and filter system.

These assumptions are necessary as the solar heater, once installed, will be completely dependent upon your pool's filter pump to push water in and through the heater's solar coils.

How It Works

When properly installed, the solar heater will be connected to your filter and your pool by two hose connections: One hose will feed cold, filtered pool water from your pump into one port of the solar heater. The other hose will feed sun warmed water from the other port of the solar heater to your pool via the pool return inlet in your pool. As cold water is fed into the solar heater, it travels through the solar coils where it is heated by the sun before it is delivered back into your swimming pool.

Unpacking Your Solar Heater

Carefully remove the product and all component parts from the box. Make certain all parts are present before beginning assembly (see Section 2, Parts List/Reference).

Tools & Equipment Required

The following items are not included with your new solar heater, but will be required for proper installation and operation:

- #2 Phillips screwdriver
- ¼" Flat head screwdriver
- Silicone based lubricant

Know Your Pool

Before you begin installation it is a good idea to know certain specifications about your pool:

How big is your pool?

How many gallons does it hold?

What size hose does it use? (i.e. 1¼" dia, 1½" dia or 2¼" dia)

What kind of hose connection does your pool use? (i.e. threaded/unthreaded)

What location will position the heater for maximum sun exposure?

Solar Heater Location

Your solar heater needs to be located on a hard level surface. You will need to position the heater lower than the pool's water level and at a safe distance away from the pool (see Section 1, Safety Warnings).

- The unit(s) should never be placed on the roof of any structure, or more than 60" above the water level of the pool.
- The unit(s) may be angled toward the sun using the legs provided. Do not exceed the angle the legs produces, or 30 degrees from horizontal in any direction.







NOTE: The solar heater is to be installed between the filter and the pool water inlet, AFTER the water is filtered. The heater must come after the filter to prevent buildup in the tubing.

IMPORTANT: If you are using a chlorine generator OR an in line chlorinator, it must be connected in-line following the solar heater to prevent damage to the heater.

CAUTION: BEFORE LOOSENING ANY THREADED CONNECTIONS ON YOUR FILTER, PUMP OR POOL, BE SURE THE SUCTION AND PRESSURE HOSES ON THE FILTER ARE CLOSED OR BLOCKED TO PREVENT WATER FLOW.

IMPORTANT: To reduce heat loss, use a pool cover on your pool overnight.

3. PARTS LIST/REFERENCE

Main Unit (1)		1¼"-1 ½" Hose Reducer (2)		Collar (2)			
							
Hose Clamp (2)		Flat Gasket (2)		Hose Adapter with O-Ring (2)		Filter Hose (2)	
							
Adapter with O-Ring for INTEX® Pools (2)				Adapter with O-Ring for BESTWAY® Pools (2)			
 Only used with 2¼" diameter threaded hoses				 Only used with 2¼" diameter threaded hoses			
Owner's Manual							


Note: Some parts may be pre-installed at the factory. Parts not shown to scale.

4. INSTALLATION INSTRUCTIONS


Heater – Filter – Pool Layout

The system layouts below will help you install the solar heater(s) to your above ground pool.

BEFORE INSTALLING SOLAR HEATER



AFTER INSTALLING SOLAR HEATER



NOTE: Not shown to scale

1. Solar Heater Placement

Extend the two legs on the underside of the heater and face the heater in the direction of the sun's natural path. See Figure 1.

Heater - Pool Connections

These instructions assume that the pool and filter system are already assembled and there is a hose attached to the pool return (pool water inlet).

Place the solar heater in a location where it will receive the greatest amount of sunlight and at least 10 feet away from pool.

2. Heater - Filter Pump Connection

- Turn off filter pump.
- Block water flow at both the pool return inlet and the filter pump outlet to prevent water from flowing through the hoses.
- Detach the pool return hose from your filter system and set aside.
- Depending on the orientation of your pump setup and desired heater placement, choose one side to be the inlet and the other to be the outlet.
- Locate long filter hose and attach between pump (the port where the pool return hose was previously connected.) and the inlet using the included hose clamps .

NOTE: Depending on the size of your hose, the 1¼"-1½" reducer may be needed. Insert the reducer inside of the filter hose and attach using hose clamp. Apply a small amount of silicon based lubricant to the outside of the reducer to allow an easy fit.






Figure 1



3. Heater – Pool Connections

NOTE: If your pool is plumbed with heavy-duty, reinforced flex hose, contact your local pool retailer for an available GAME adapter kit (item 4553).

A) Pools with 1 $\frac{1}{4}$ " or 1 $\frac{1}{2}$ " Diameter Unthreaded Hoses

Connect the hose adapter into the heater port. Secure with the collar. Attach the hose (from the filter) and secure with a hose clamp. Repeat on the other side of the heater, connecting the hose to the pool. See figure 2.

OR

B) Pools with 2 $\frac{1}{4}$ " Diameter Threaded Hoses

Connect the hose adapter into the heater port. Secure with the collar. Attach the adapter for either Intex (use flat gasket as shown if needed) or Bestway to the heater port. Be sure the o-ring is in the adapter before attaching. Attach the hose (from the filter) and secure with a hose clamp. Repeat on the other side of the heater, connecting the hose to the pool. See figure 3.

NOTE: If solar heater needs to be further from the filter than the hoses allow, you may need to purchase a longer hose with the 1 $\frac{1}{2}$ " diameter openings. A 1 $\frac{1}{2}$ "-1 $\frac{1}{2}$ " coupler is needed to allow you to connect an additional hose if necessary (not included). In this case make certain you have two hose clamps to secure the hoses to the coupler. If the hoses are too wide to fit the hose connector, use the 1 $\frac{1}{4}$ "-1 $\frac{1}{2}$ " tube reducer on the hose connector and continue.

CAUTION: ENSURE ALL HOSE CONNECTIONS ARE TIGHT AND THE HOSES ARE NOT KINKED OR BENT AT SEVERE ANGLES. IF THE HOSES ARE LEAKING, CHECK TO MAKE SURE ALL OF THE PARTS THAT HAVE O-RINGS HAVE THEM ATTACHED AND ARE SCREWED ON TIGHTLY. DO NOT OVER TIGHTEN HOSE CLAMPS (35 IN/LB MAX TORQUE)

4. Initial Operation

Once the solar heater has been assembled and the hoses are connected to the filter pump and pool return, unblock the flow of water into the pool return hose and turn on the pump and filter system. Bubbles will shoot out of the return nozzle into the pool initially while air is pushed out of the solar heater. If this persists for longer than 2 or 3 minutes, check for and repair any leaks in the hoses or connections.

FOR BEST RESULTS: To reduce heat loss, use a pool cover on your pool overnight, run your filter system during daylight hours and cover the solar heater at night (if running the system).

5. INITIAL OPERATION

Once the solar heater has been assembled and the hoses are connected to the filter pump and pool return, unblock the flow of water into the pool return hose and turn on the pump and filter system. Bubbles will shoot out of the return nozzle into the pool initially while air is pushed out of the solar heater. If this persists for longer than 2 or 3 minutes, check for and repair any leaks in the hoses or connections.

FOR BEST RESULTS: To reduce heat loss, use a pool cover on your pool overnight, run your filter system during daylight hours and cover the solar heater at night (if running the system).

6. MAINTENANCE

The solar heater should not require servicing or maintenance other than winterizing. Prior to the first frost, or at the end of your swim season, the solar heater should be removed from its connections to the pool and stored in a frost free location.

Winterizing

Drain all the water from the solar heater by disconnecting the tubes. Store in a location protected from frost. Reconnect the pool return tubes with a 1½"-1½" coupler (not included) or any properly sized 2-way valve if continued pool use is desired.

CAUTION: DO NOT ALLOW STANDING WATER INSIDE THE SOLAR HEATER TO FREEZE. WATER EXPANDS AS IT FREEZES AND CAN RUPTURE THE SOLAR COILS ON THE HEATER.

7. TROUBLESHOOTING

Problem	Possibilities/Solutions
Does not appear to be heating the pool.	• Check to make sure that water is flowing through the holes. Check the flow strength at the pool inlet. • Has it been sunny? • Put your pool cover on at night to prevent heat loss. • Additional heaters may be necessary. • If using a bypass kit, check and adjust flow restrictions if necessary.
No initial bubbling after heater is connected and pump is on.	• Check the setting of the filter to make sure it is returning water to the pool through the pool water inlet. • Check flow rate.
Bubbles continue to flow out of the pool water inlet well after the pump has been turned on.	• Check the connections for a suction leak. • Check to make sure the flow rate is normal. • There could be a break in the tubing. • There could be a clog in the tubing, try to purge out the clog.
Leaking heater	• Check the connector seals and replace or repair if defective.
High filter pressure	• Flow through heater may be too high. A bypass kit may be needed. • Filter may need backwashing or filter media change. • Pool/spa system valves may need adjusting. • Water return outlet may be blocked.

8. LIMITED WARRANTY STATEMENT

The manufacturer warranties safe operation and reliability only under the following conditions:

- The solar heater is installed and operated according to the assembly and operating instructions.
- Only original replacement parts are used.
- Consumable parts do NOT fall under the warranty.

General Terms

This Limited Warranty applies to the enclosed product (the "Product") distributed by Great American Duck Races, Inc., an Arizona corporation (doing business as Great American Merchandise and Events) ("GAME").

GAME warrants that the Product will be free from defects in materials and workmanship under normal use for a period of ninety (90) days from the date of purchase. (Your dated sales or delivery receipt, showing the date of your Product purchase, is your proof of the purchase date.) During the warranty period, GAME will repair or replace any defective parts at no charge.

All defective parts that are replaced by GAME will be replaced, at GAME's discretion, with either new parts or used parts that meet or exceed performance specifications for new parts. All parts removed from the Product under this warranty will become the property of GAME. Repair or replacement of any parts will not serve to extend the ninety (90) day warranty period.

This Limited Warranty does not apply to expendable parts. This Limited Warranty does not extend to any product (a) from which the serial number has been removed or (b) that has been damaged or rendered defective (i) as a result of accident, misuse, abuse or other external causes; (ii) by operation outside the usage parameters stated in the Instruction Sheet that shipped with the Product; (iii) by the use of parts not manufactured or sold by GAME; or (iv) by modification or service by anyone other than GAME or an authorized GAME distributor.

If a defect is identified within the warranty period, please contact GAME.

EXCEPT FOR THE LIMITED WARRANTY SET FORTH ABOVE, GAME EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, ORAL OR STATUTORY (INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE). ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW ARE LIMITED TO THE TERMS OF THE ABOVE LIMITED WARRANTY.

Limitation of Liability

EXCEPT FOR THE LIMITED WARRANTY DESCRIBED ABOVE, IN NO EVENT WILL GAME HAVE ANY LIABILITY OF ANY KIND WHATSOEVER (WHETHER UNDER CONTRACT, TORT, OR ANY OTHER THEORY OF LEGAL LIABILITY) TO ANY PERSON WITH RESPECT TO THE PRODUCT (INCLUDING, WITHOUT LIMITATION, (A) ANY USE OR MISUSE OF THE PRODUCT, (B) ANY FAILURE OR MALFUNCTION OF THE PRODUCT, (C) ANY BODILY INJURY, DEATH, LOSS OF OR DAMAGE TO ANY PROPERTY, OR ANY OTHER DAMAGES RELATED TO OR RESULTING FROM THE PRODUCT OR ITS USE (INCLUDING, WITHOUT LIMITATION, ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, LOST PROFITS, LOSS OF USE), EVEN IF GAME OR GAME'S AUTHORIZED REPRESENTATIVES HAVE BEEN ADVISED OF THE POSSIBILITY OF ANY SUCH DAMAGES.

TO OBTAIN WARRANTY SERVICE, PLEASE CALL, WRITE, OR EMAIL US DIRECTLY AT THE ADDRESS SHOWN BELOW.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

Severability

Any provision of this Limited Warranty which is prohibited or unenforceable in any jurisdiction will, as to such jurisdiction, be ineffective to the extent of such prohibition or unenforceability without invalidating the remaining portions hereof or affecting the validity or enforceability of such provision in any other jurisdiction.

Venue and Choice of Law

This Limited Warranty is applicable in all countries. This Limited Warranty will be governed by the laws of the State of Arizona (regardless of any conflict of laws rules), and any disputes arising from this Limited Warranty will be resolved in Phoenix, Arizona.

Entire Agreement

This Limited Warranty is understood to be the complete and exclusive agreement between GAME and the purchaser of the Product, superseding all prior agreements, oral or written, and all other communications between such parties relating to the Product. No employee or representative of GAME or any other party is authorized to make any warranty in addition to the limited warranty set forth above.

To obtain warranty service, please call, write, or email us directly at the address shown below.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

IMPORTANT DO NOT RETURN PRODUCT TO STORE

For technical assistance and missing parts, call Customer Service toll-free

1.888.339.2546

(press 135 at any time)

Monday through Thursday, 8:00 am to 5:00 pm MST


Friday, 8:00 am to 2:00 pm MST

Please visit our website, www.game-group.com, for potential updates to these instructions.

9. APPENDIX: EXPLODED PARTS DIAGRAM

Key	Name	Qty	Item Number
1	Heater Main Body	1	NA
2	1-1/2" Hose, 1m	2	4K9023
3	Rubber Reducer	2	4P6013
4	Cap nut	2	4K9022
5	Adaptor with o-ring	2	4K9022
6	1-1/2" Stainless Steel Clamp	2	4K9023
7	Long Intex adaptor with o-ring	2	4K3001
8	Gasket	2	4K3001
9	Support Foot	2	4S1080

Note: Some parts may be pre-installed at the factory. Parts not shown to scale.



IMPORTANT
DO NOT RETURN PRODUCT TO STORE

For technical assistance and missing parts, call Customer Service toll-free

1.888.339.2546

(press 135 at any time)

Monday through Thursday, 8:00 am to 5:00 pm MST

Friday, 8:00 am to 2:00 pm MST

Please visit our website, www.game-group.com, for potential updates to these instructions.

**Look for other GAME products at your favorite store
or visit our website, www.game-group.com.**



/GAMEproducts



Great American Merchandise & Events™
16444 N. 91st Street
Scottsdale, AZ 85260-1567 U.S.A.

tel: 888.382.5988, 602.957.3825
fax: 602.957.7665
email: products@game-group.com
www.game-group.com/retailers

Intex® is a registered trademark of Intex Recreation Corp. GAME is not affiliated with, sponsored by, or otherwise associated with Intex Recreation Corp.

Bestway® is a registered trademark.