

Vinyl Stickon Installation Instructions

One installation kit will install 40 6x6 vinyl stickons or 22 8x8 vinyl stickons.

Our installation kit must be used for all applications.

1. Prepare Surface

- Surface should be a dry, flat plane, and free of loose debris
- High spots should be ground off and voids filled in

2. Spray Adhesive

- Mask off the perimeter to reduce clean up
- Spray the application area with aerosol adhesive
- Allow spray to dry for 15 minutes (*****important! Stickons will fail if not allowed to dry!***)
- Spray adhesive will become slightly tacky

3. Install Marker

- Remove the paper backing from the stickon
- Apply the stickon to the sprayed area
- Firmly press and drag the plastic applicator over the entire surface to eliminate air pockets

4. Edge Sealer

- Apply edge sealing compound to the entire perimeter of the stickon
- Important – Make sure edge sealer overlaps both the stickon and the deck surface –this ensures a moisture proof seal
- Allow stickon to set overnight before permitting traffic