# Vinyl Stickon Installation Instructions

*One installation kit will install 40 6x6 vinyl stickons or 22 8x8 vinyl stickons.*
*Our installation kit must be used for all applications.*

## 1. Prepare Surface

- Surface should be a dry, flat plane, and free of loose debris
- High spots should be ground off and voids filled in

## 2. Spray Adhesive

- Mask off the perimeter to reduce clean up
- Spray the application area with aerosol adhesive
- Allow spray to dry for 15 minutes ***(**important! Stickons will fail if not allowed to dry!)***
- Spray adhesive will become slightly tacky

## 3. Install Marker

- Remove the paper backing from the stickon
- Apply the stickon to the sprayed area
- Firmly press and drag the plastic applicator over the entire surface to eliminate air pockets

## 4. Edge Sealer

- Apply edge sealing compound to the entire perimeter of the stickon
- Important – Make sure edge sealer overlaps both the stickon and the deck surface –this ensures a moisture proof seal
- Allow stickon to set overnight before permitting traffic

5603 Executive Circle • Little Suamico, WI 54141
**(920) 337-4680 • Fax (920) 337-4681 • (800) 426-6873 • Fax (800) 926-6873**