



COPPER

TEST KIT

Code 3619

COPPER TEST KIT

Code 3619

*Potential Health Hazard: Read product label before use. See lamotte.com for SDS.

<p>1.</p> <p>Fill tube (0106) to the 10 mL line with sample water.</p> 	<p>2.</p> <p>Add 5 drops of Copper A (P-6367) to tube.</p> 	<p>3.</p> <p>Cap and invert tube to mix.</p> 	<p>4.</p> <p>Remove cap and add 5 drops of *Copper B (P-6368) to tube.</p> 	<p>5.</p> <p>Cap and invert tube to mix.</p> 
<p>6.</p> <p>Insert tube into holder. Wait 3 minutes for full color development. Remove cap.</p> 		<p>7. Place bottom of tube on white area of color chart. Look down through the tube to match the sample color to a standard.</p> <p>NOTE: Always empty and rinse tubes promptly after testing to avoid staining.</p> 		

WARNING! This set contains chemicals that may be harmful if misused. Read cautions on individual containers carefully. Not to be used by children except under adult supervision

LaMotte Company • PO Box 329
Chestertown • Maryland • 21620 • USA