

A Water Based Decorative Concrete Stain

DESCRIPTION & USE

Multicoat's MULTI-STAIN is a water based stain designed to be applied to a variety of Multicoat's Systems. It can also be applied on most cementitious substrates such as pool decks, driveways, walkways, masonry walls, stucco, pre-cast concrete, etc. MULTI-STAIN is an acrylic based concrete stain furnished in factory blended containers. It is used as a decorative color stain for most cementitious substrates.

ADVANTAGES:

- Green Friendly
- Save to Use
- Water Based Cleans up with Water
- Easy to Apply
- Can be Sprayed or Rolled
- Low Cost
- Wide Color Selection
- Quick Drying

AVAILABLE IN ONE AND FIVE CALLON

AVAILABLE IN ONE AND FIVE GALLON CONTAINERS

SURFACE PREPARATION

Surface to which MULTI-STAIN will be applied must be completely free from all grease, oil, paint, dirt, dust, laitance, sealers, curing compounds, water repellents and other foreign materials which may interfere with bonding. Surface must be completely dry prior to MULTI-STAIN application. Concrete surfaces should be etched with acid to open pores to achieve proper effect of stain. Acid must be neutralized with soda ash, baking soda, etc., before application. When using over Multicoat's TOP COAT or KRETE KOTE, we recommend a light sanding prior to staining. Do not use acid to clean TOP COAT, KRETE KOTE, MICRO-TOPPING or STAMP MIX. Be sure surface is completely cured.

MIXING

MULTI-STAIN must be thoroughly stirred and shaken prior to use. Do not add water: use at full strength. All pails of like color stain should be combined into one container prior to use during application for uniformity.

APPLICATION

Apply MULTI-STAIN in one coat. Can be applied with a pump sprayer (recommended application), airless sprayer, by roller, sponge or broom. Apply stain generously to substrate to achieve desired color. Color will lighten slightly as it dries. Final color can be darkened by applying subsequent coats of stain: allow each coat to dry thoroughly. Then apply Multicoat's CLEARSEAL to entire area stained.



APPLY MULTI-STAIN WITH A PUMP SPRAYER AS SHOWN ABOVE. CAN ALSO BE SPONGED OR BROOMED.



AS SOON AS MULTI-STAIN HAS DRIED, USUALLY THE NEXT DAY, APPLY 2 COATS OF MULTICOAT'S CLEAR SEAL TO LOCK IN THE COLOR AND PROTECT THE SURFACE.

