

Spa Purge™ Instructions

Directions for use:

Spas/Hot Tubs:

- 1. Remove cartridge filter elements.
- 2. With spa water temperature at 95°F or higher and circulation running, add entire contents of bottle to spa water.
- 3. Run jets for a minimum of 5 minutes.
 - **Note:** If foaming becomes excessive, turn jets off. Some foaming is expected during the purge process.
- 4. Maintain water temperature at 95°F and allow spa to circulate overnight with jets off.
- 5. Drain and rinse/clean out the surfaces of the spa. Refill the spa water and reinstall the filter elements.
- 6. Proceed with normal spa maintenance.

For Jetted Tubs:

- 1. Fill tub with hot water 1" above the jets.
- 2. Add 1/2 bottle of Spa Purge.
- 3. Turn jets on for 5 minutes (some foaming will occur).
- 4. Turn jets off and let sit for at least 5 hours.
- 5. Turn jets on to flush the system.
- 6. Drain tub & clean surface as needed.