

Polyspun Instructions

Vea la página 2 para Español (See page 2 for Spanish)



Applications:

- ▶ Gardens and landscapes
- ▶ Underlayment
- ▶ Separation

Benefits:

- ▶ Creates a weed barrier
- ▶ Allows air, water and nutrients to pass through

Instructions:



1. Prepare Area

Remove all weeds from the desired area. For added protection, apply pre-emergent herbicide before laying down fabric.



2. Place Fabric

Unroll fabric and cut to desired length. Fit fabric around plants, lights, etc., by cutting slits or an "X" where needed overlapping each section 4-6 inches. Secure fabric with SRW Fabric Staples, staggering 1.2 staples per square yard.



3. Cover Fabric

Cover with 3-4 inches of mulch, stone or bark to protect fabric from sunlight and to enhance the appearance of your project.

WEED CONTROL



*FRONT AND BACK DETAIL



Aplicaciones:

- ▶ Jardines y paisajismo
- ▶ Base de piso
- ▶ Separación

Beneficios:

- ▶ Crea una barrera para la maleza
- ▶ Permite que pase el aire, el agua y los nutrientes

Instrucciones:



1. Prepare el área

Quite todas las malezas del área deseada. Para mayor protección, aplique herbicida pre-emergente antes de colocar la tela.



2. Coloque la tela

Desenrolle la tela y córtela del largo deseado. Ajuste la tela alrededor de plantas, luces, etc. haciendo cortes o una "X" donde se necesita superponer cada sección 4 a 6 pulgadas. Asegure la tela con Grapas para Tela SRW, intercalando grapas de 1,2 por yarda cuadrada.



3. Tela de cubierta

Cubra con 3 a 4 pulgadas de abono, piedra o corteza para proteger la tela de la luz del sol y para mejorar la apariencia de su proyecto.

WEED CONTROL



*FRONT AND BACK DETAIL