

SOLAR REFLEX

by **audioBOMB™**



Included:

Solar Reflex Charger
USB charging cable
Carabiner

Instruction Manual

Specifications

- Battery Type: Li-Polymer
- Capacity: 5000mAh
- Input: 5V/1A
- Output: 5V/2X1A
- Solar Panel: 5.5V/1.2W
- Product Dims: 142x75x13.6mm
- Product Weight: 146g
- Color: Red/Gray/Blue
- AC charge time: 6-7 hours
- Solar charge time: 16-18 hrs

Get Started First, fully charge your Solar Reflex in a power outlet. To charge a device from your Solar Reflex, plug the USB end of your device's charging cable into either port on the Solar Reflex. Plug the opposite end of that cable into your device. Hit the Power button once to begin charging. The blue LED light bars indicate amount of battery power available.

Two Ways to Charge your Solar Reflex:

1. Use the Cable

- The first full charge must use the MicroUSB cable provided.
- Plug the MicroUSB end of the cable into the Solar Reflex.
- Plug the USB end of the cable into a cable adapter for use with an outlet, or plug the USB directly into a computer.

2. Use the Sun

- Placing in direct sunlight for 8-9 hours will charge the Solar Reflex 50%. For best results, angle the solar panel towards the sun during the hours of 11am-3pm.
- Sunlight through windows is not considered direct sunlight.

Features

Adventure Proof

- Waterproof
- Dustproof
- Shockproof

Light the Way

- Press the power button twice to turn on the LED flashlight.
- Repeat to turn it off.

Charge two devices at once

- There are two USB ports on the Solar Reflex, so you can recharge up to two devices at the same time.

Blue and Green LED Indicator Lights

- Press the power button once to show the Blue LED indicator lights. The Solar Reflex is fully charged when 5 bars are glowing blue.
- Green LED indicates the solar panel is charging.

Protection and Warranty:

Safety & More

- Although your charger is made for the sun, please do not expose to extreme temperatures beyond the outdoor temperature. Please do not charge and discharge at the same time. Do not dispose of your device in fire, water or directly short circuit.

Warranty Information

- With this purchase, you get a 1-year manufacturer warranty. This does not protect against any defect or malfunction that is caused as a result of misuse, failure to follow operating instructions, abuse, or use with improper or fault equipment. It doesn't cover incidental damages. Note: This product is not made to be submerged in water

Visit us at:
WWW.AUDIOBOMB.COM
for more great products