

**CASTOHN**<sup>®</sup>



WEST REGION

**FIRE PIT KITS**



**CASTOHN**<sup>®</sup>

For additional product information, please visit [castohn.com](http://castohn.com)




### Round Belvedere Fire Pit

cap included




Pallet: 1,300 lbs

### Top View




### Small Round Dimensional Fire Pit

no cap




Pallet: 1,150 lbs


### Top View



### Block Layout Pattern For Round Belvedere Fire Pit



### Cross-Section




### Square Dimensional Fire Pit

no cap




Pallet: 1,150 lbs




### Kodah Fire Pit

no cap



Pallet: 1,650 lbs



### Available Colors\* - West Region



Silver Legacy



Western Buff



Pacific Mist

\*colors may vary, see actual pallets

### INSTRUCTIONS: For Both Round & Square Fire Pit Kits

1. Familiarize yourself with the construction details shown on this page.
2. Mark out the location for your fire pit. Note dimensions shown are nominal so mark an area slightly larger than shown.
3. Excavate for drain stone base (approx. 6")
4. Fill excavated area with drain stone, level, and compact.
5. Place and center steel ring on prepared base.
6. Place blocks per the pattern (for round kit, keep blocks 1½" off steel ring).
7. **WARNING:** Do not place fire pits directly on flagstone products or any comparable concrete product as high heat can adversely affect the integrity of the product.

### Following Steps For Round Fire Pit Only

8. After placing blocks around the ring, adjust the blocks in or out to make the circle close and fit tight. If the blocks do not close the circle, move all blocks slightly in. If the blocks seem too long, move the blocks slightly out.
9. Place caps in circle around fire pit. Adjust the caps in or out to make them fit tightly together.
10. Note: Not suitable for large fires. Fire size shouldn't allow flame to contact caps on round fire pit.

Gas Conversion Kits Available