LIMITED WARRANTY STATEMENT

General Terms

This Limited Warranty applies to the product enclosed ("the Product") distributed by Great American Duck Races, Inc., an Arizona corporation, doing business as Great American Marketing and Events ("GAME"), sold with this Limited Warranty Statement. This Limited Warranty is applicable in all countries.

GAME warrants that the Product you have purchased from GAME is free from defects in materials or workmanship under normal use during the warranty period. The warranty period starts on the date of purchase and continues for ninety (90) days. Your dated sales or delivery receipt, showing the date of purchase of the Product, is your proof of the purchase date.

During the warranty period, GAME will repair or replace any defective parts with new parts, or, at GAME's discretion, used parts that meet or exceed performance specifications for new parts. All parts removed under this warranty become the property of GAME. The replacement part takes on the warranty status of the removed part or product. This Limited Warranty does not apply to expendable parts. This Limited Warranty does not extend to any product from which the serial number has been removed or that has been damaged or rendered defective (a) as a result of accident, misuse, abuse or other external causes; (b) by operation outside the usage parameters stated in the Instruction Sheet that shipped with the Product; (c) by the use of parts not manufactured or sold by GAME; or (d) by modification or service by anyone other than GAME.

Limitation of Liability

GAME is not liable for any damages caused by the Product or the failure of the Product to perform, including any direct or indirect damages for personal injury, lost profits, lost savings, incidental damages, consequential damages, or any other pecuniary loss arising out of the use or inability to use the Product. GAME is not liable for any claim made by a third party or made by you for a third party.

This limitation applies whether damages are sought, or a claim made, under this Limited Warranty or as a tort claim (including negligence and strict product liability), a contract claim, or any other claim. This limitation cannot be waived or amended by any person. This limitation of liability will be effective even if you have advised GAME or an authorized representative of GAME of the possibility of any such damages.

EXCEPT AS EXPRESSLY SET FORTH IN THIS LIMITED WARRANTY, GAME MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. GAME EXPRESSLY DISCLAIMS ALL WARRANTIES NOT STATED IN THIS LIMITED WARRANTY. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW ARE LIMITED TO THE TERMS OF THIS WORLDWIDE LIMITED WARRANTY STATEMENT.

To obtain warranty service, please call, write, or email us directly at the address shown below. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.





/GAMEproducts

Great American Merchandise & Events" (GAME"), Scottsdale, AZ 85260 USA 888.339.2546 www.game-group.com Designed in the USA. © 2016 GAME. All rights reserved. Made in China.





ASSEMBLY INSTRUCTIONS





USE AND CLEANING INSTRUCTIONS

The Pool & Spa Vacuum by GAME simplifies all your spa and pool needs. Cleanup is easy - the simple pump action creates suction that draws in water and debris from the pool or spa as you pull the handle out. Push the handle in and the dirt and debris are trapped inside the special filter basket as the water flows out. The vacuum requires no special hoses or hookups. It comes with a Narrow Nozzle (attached), a Wide End Nozzle (attaches to the Narrow Nozzle) and a specially designed Slide-On Brush.

CAUTION: DO NOT SCRAPE VACUUM OR NOZZLES AGAINST ACRYLIC SPAS AS THIS WILL DAMAGE THE SURFACE OF THE SPA.

CLEANING YOUR SPA OR POOL

Always start by priming the unit by placing the nozzle end of the Vacuum underneath the surface of the water. Pump the unit's handle in and out several times to remove air that may be trapped in the Vacuum. Always begin with the handle pushed completely in. Pull the handle out to draw debris in.

- Use the Narrow Nozzle to remove rocks and debris.
- To remove dirt, attach the Wide End Nozzle to the Narrow Nozzle.
- Slide the Brush onto the Wide End Nozzle to scrub stubborn dirt spots.

EMPTYING THE FILTER BASKET (See illustrations below)

- 1. Twist and pull the Narrow Nozzle to remove.
- 2. Grasp the plastic band at the base of the screen. DO NOT GRASP THE FILTER BASKET SCREEN! Gently rotate the Narrow Nozzle counterclockwise you until you feel it stop.
- 3. Gently pull the Filter Basket from the nozzle. Empty the basket and rinse clean with water.
- 4. Replace the basket on to the nozzle and turn clockwise to lock it into position.

NOTE: ALWAYS DRAIN EXCESS WATER FROM THE UNIT AFTER USE BY REMOVING THE FILTER UNIT.

4







Trap Trap

Filter Basket