




**WINGMASTER®  
PLUS**

## WINGMASTER® JET KEY



### Wingmaster® Jet Key Uses:

1. Screwdriver.
2. Install/remove 3-way Hayward valve unions.
3. Install/remove directional fittings.
4. Use hex bar through center hole for more turning and torque.
5. Install/remove Polaris/Letro universal wall fittings.
6. Install/remove Waterway Poly Jet face rings.
- 7-8. Install/remove Hayward jet nozzle retaining rings or broken ring tips.
9. Install/remove Hydro-Air spa jet face ring.
10. Install/remove Hydro-Air (Slim-line) face ring.

[www.wingmasterplus.com](http://www.wingmasterplus.com)


Ph: 888-784-0747

American Granby - Liverpool, NY



**WINGMASTER®  
PLUS**

## WINGMASTER® JET KEY



### Wingmaster® Jet Key Uses:

1. Screwdriver.
2. Install/remove 3-way Hayward valve unions.
3. Install/remove directional fittings.
4. Use hex bar through center hole for more turning and torque.
5. Install/remove Polaris/Letro universal wall fittings.
6. Install/remove Waterway Poly Jet face rings.
- 7-8. Install/remove Hayward jet nozzle retaining rings or broken ring tips.
9. Install/remove Hydro-Air spa jet face ring.
10. Install/remove Hydro-Air (Slim-line) face ring.

[www.wingmasterplus.com](http://www.wingmasterplus.com)

Ph: 888-784-0747

American Granby - Liverpool, NY