

audioBOMB

BLUETOOTH SPEAKER


User Guide



Package Contents:



Charging Cable (USB to Micro-USB)



User Guide

Specifications:

Size: 2.44" x 2.32" (62mm x 59mm)

Weight: 3.17 oz. (90g)

Rated Power: 3 Watts

Interface: Micro-USB

Bluetooth:

Operating Frequency: 2.400GHz - 2.480GHz

Peak Power Output: Class 2/4 dbm

Receiving Sensitivity: -91db @ 0.1% BER

Range: Approximately 33' (10m)

Battery:

Type: Polymer Li-ion




Capacity: 400mA, 3.7V

Operating Time: 2.5 hours at 100% volume

4.5 hours at 50% volume

Charging Standard: DC 5V, 500mA

Charging Time: 1.5-2 Hours



At A Glance:

- 1) **Interface Dust Cover**
- 2) **Micro-USB Charging Port**
- 3) **On/Off Switch**
- 4) **Volume Down/Skip Back Button** - Press and hold to decrease the volume. Press for two seconds and release to skip back through songs.
- 5) **Play/Pause Button** - When listening to music, press for two seconds and release to pause playback. Press for two seconds and release to resume playback. **If your speaker has also been paired with your phone and there is an incoming call**, the music will pause and your ringtone will sound. Press this button to answer the call. Press and hold this button at any time to redial the last call.
- 6) **Volume Up/Skip Ahead Button** - Press and hold to increase the volume. Press for two seconds and release to skip ahead through songs.
- 7) **Microphone** - Used during hand-free calling.
- 8) **Suction Cup** - Will adhere firmly to most smooth surfaces. Works best if dampened before use.
- 9) **LED Indicator**
 - Red Light On** - Charging. Light goes out when charged.
 - Blue Light Blinking Quickly** - In Bluetooth Pairing Mode.
 - Blue Light Blinking Slowly** - Pairing with a device.
 - Blue Light On** - Paired with a device.

IMPORTANT: Please make sure that your speaker is fully charged before first use.

- 1) Open the Interface Dust Cover.
- 2) Insert the Micro-USB end of the Charging Cable into the Micro-USB Charging Port.
- 3) Insert the USB end of the Charging Cable into a USB port on your computer. You can also use a USB-enabled wall charger that has a current of 1 Amp or less.




Pairing the speaker with a Bluetooth-enabled Smartphone, Tablet, or Other Device

- 1) Make sure the device with which you want to pair the **speaker** has its Bluetooth setting in the "On" position and that it is searching for devices.
- 2) Open the Interface Dust Cover and switch your **speaker** on. The blue LED on the bottom should blink quickly to show that the **speaker** is in pairing mode.
- 3) Find and select "**Squish**" on your device.
- 4) The **speaker** will beep and the blue LED on the bottom will blink slowly, about one time per second, to show that it has successfully paired with your device.

Using the speaker as a Phone or Tablet Stand

The **speaker** can be used as a handy phone or tablet stand. Simply adhere the suction cup to the back.



PLEASE NOTE: The durable silicone gel casing makes the **speaker** splash resistant and suitable for use in damp and harsh environments. However, it is not waterproof and care should be taken to make sure that the **speaker** does not get submerged in water.

Troubleshooting

The **speaker** should work well within the effective range of approximately 33' (10m). If it does not, please try the following:

- 1) Make sure that your **speaker** is charged up and turned on.
- 2) Make sure that the device with which you want to pair has its Bluetooth setting in the "On" position and is within the effective range of 33' (10m).
- 3) Move your **speaker** and/or Bluetooth Device away from sources of electromagnetic interference such as cordless phones, microwave ovens, wireless network routers, or other Bluetooth devices.
- 4) If you hear a "pop" noise every two songs during music playback, your device is not fully compatible with your **speaker**.
- 5) If you have difficulty connecting your device with your **speaker** after it has been paired with your device, delete it from your device and re-pair.
- 6) If you have too many Bluetooth devices listed under "Devices" the pairing process may take longer or be unsuccessful. Delete one or more of the devices to improve pairing performance.

How to Properly Dispose of Batteries

This product contains a lithium-ion battery. To properly dispose of expired batteries, view your city's website or newsletter to find what guidelines, if any, should be followed and to make note of their hazardous waste collection days.

Technical Support

If you have any questions about the operation and/or performance of this product that were not covered in this user guide, please email info@audiobomb.com for assistance.

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: a) Reorient or relocate the receiving antenna b) Increase the separation between the equipment and receiver c) Consult the dealer or an experienced radio/TV technician for help.

Note 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Important Note

FCC Radiation Exposure Statement:

1. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance.

2. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

