

Technical Data Sheet

F-1000 Series - Digital Paddlewheel Flowmeter with Saddle & Tee Fittings

F-1000 Features:

- Easy to read 6 digit LCD, up to 4 decimal positions. Tamper proof.
- Battery operated (2 AAA batteries included). 3 model variations:
 - RB = RATE ONLY
 - TB = TOTAL ONLY
- RT = RATE & TOTALIZER
- Total reset function can be disabled.
- Display update time: Rate 1.5 sec., Total 0.5 sec.
- Factory calibrated nothing to program.
- Custom calibration units available. Contact the factory.
- Weather resistant ABS enclosure. NEMA 4X
- LCD is not recommended for direct sunlight applications.

F-1000 Specifications:

Max. Fluid Temperature 200° F (93° C) @ 0 PSI (all PVDF saddles and SS Tee fittings) 140° F (60° C) @ 0 PSI (all PVC saddles and PVC Tee fittings) Note: Temperature rating of F-1000 only. Actual pipe rating may vary.

Full scale accuracy +/- 2%

Saddle material..... PVDF (1-1/2", 2", 3", 50mm, 63mm, 90mm sizes)

PVC (all other sizes)

Sensor/Paddle/Axle material . PVDF

O-ring seals: Viton

Max. pressure drop: 0 psi (no significant pressure drop)

Approximate shipping weight. 2 lb. (.91 kg)

Saddle Mount **316 Stainless Steel Tee** RT-300S8-GPM1 RT-100ST-GPM1

PVC Tee RT-200AT-GPM1



Pipe Size	GPM Flow Range	RATE ONLY Model Number	TOTAL ONLY Model Number	RATE & TOTAL Model Number	RATE ONLY Model Number	TOTAL ONLY Model Number	RATE & TOTAL Model Number
1-1/2"	15 to 150	RB-150S4-GPM1	TB-150S4-GPM1	RT-150S4-GPM1	RB-150S8-GPM1	TB-150S8-GPM1	RT-150S8-GPM1
2"	30 to 300	RB-200S4-GPM1	TB-200S4-GPM1	RT-200S4-GPM1	RB-200S8-GPM1	TB-200S8-GPM1	RT-200S8-GPM1
2-1/2"	40 to 400	RB-250S4-GPM1	TB-250S4-GPM1	RT-250S4-GPM1	RB-250S8-GPM1	TB-250S8-GPM1	RT-250S8-GPM1
3"	60 to 600	RB-300S4-GPM1	TB-300S4-GPM1	RT-300S4-GPM1	RB-300S8-GPM1	TB-300S8-GPM1	RT-300S8-GPM1
4"	100 to 1000	RB-400S4-GPM1	TB-400S4-GPM1	RT-400S4-GPM1	RB-400S8-GPM1	TB-400S8-GPM1	RT-400S8-GPM1
6"	250 to 2500	RB-600S4-GPM1	TB-600S4-GPM1	RT-600S4-GPM1	RB-600S8-GPM1	TB-600S8-GPM1	RT-600S8-GPM1
8"	400 to 4000	RB-800S4-GPM1	TB-800S4-GPM1	RT-800S4-GPM1	RB-800S8-GPM1	TB-800S8-GPM1	RT-800S8-GPM1
10"	600 to 6000	RB-1000S4-GPM1	TB-1000S4-GPM1	RT-1000S4-GPM1	RB-1000S8-GPM1	TB-1000S8-GPM1	RT-1000S8-GPM1
12"	800 to 8000	RB-1200S4-GPM1	TB-1200S4-GPM1	RT-1200S4-GPM1	RB-1200S8-GPM1	TB-1200S8-GPM1	RT-1200S8-GPM1

Models for mounting on Solvent Weld PVC TEE

			GPM MODELS	····· · ······························			LPM MODELS	
Pipe	GPM	RATE ONLY	TOTAL ONLY	RATE & TOTAL	LPM	RATE ONLY	TOTAL ONLY	RATE & TOTAL
Size	Flow Range	Model Number	Model Number	Model Number	Flow Range	Model Number	Model Number	Model Number
1"	6 to 60	RB-100AT-GPM1	TB-100AT-GPM1	RT-100AT-GPM1	25 to 250	RB-100AT-LPM1	TB-100AT-LPM1	RT-100AT-LPM1
1-1/2"	15 to 150	RB-150AT-GPM1	TB-150AT-GPM1	RT-150AT-GPM1	60 to 600	RB-150AT-LPM1	TB-150AT-LPM1	RT-150AT-LPM1
2"	30 to 300	RB-200AT-GPM1	TB-200AT-GPM1	RT-200AT-GPM1	100 to 1000	RB-200AT-LPM1	TB-200AT-LPM1	RT-200AT-LPM1
3"	60 to 600	RB-300AT-GPM1	TB-300AT-GPM1	RT-300AT-GPM1	230 to 2300	RB-300AT-LPM1	TB-300AT-LPM1	RT-300AT-LPM1
		Maa		nting on E/ND	T 246 Stai	nloss Steel 1	TEE	

Models for mounting on F/NPT 316 Stainless Steel TEE					
LPM MODELS					
NLY TOTAL ONLY RATE & TOTAL					
mber Model Number Model Number					
LPM1 TB-100ST-LPM1 RT-100ST-LPM1					
LPM1 TB-150ST-LPM1 RT-150ST-LPM1					
LPM1 TB-200ST-LPM1 RT-200ST-LPM1					



5300 Business Drive, Huntington Beach, CA 92649 • (ph) 714-893-8529 • (fx) 714-894-9492 • (em) sales@blue-white.com View Technical Data at www.blue-white.com Technical data sheet #85000-024 rev 060816





Installation Guidelines

F-1000 Series - Digital Paddlewheel Flowmeter with Saddle & Tee Fittings

Fluid Flow Stream Requirements

Measuring accuracy requires a fully developed turbulent flow profile. Pulsating, swirling and other disruptions in the flow stream will effect accuracy. Flow conditions with a Reynolds Number greater than 4000 will result in a fully developed turbulent flow. A Reynolds Number less than 2000 is laminar flow and may result in inaccurate readings.



Minimum Straight Pipe Length Requirements

The meter's accuracy is affected by disturbances such as pumps, elbows, tees, valves, etc., in the flow stream. Install the meter in a straight run of pipe as far as possible from any disturbances. The distance required for accuracy will depend on the type of disturbance.

Type Of Disturbance	Minimum Inlet Pipe Length	Minimum Outlet Pipe Length
Flange	10 X Pipe Inside Diameter	5 X Pipe Inside Diameter
Reducer	15 X Pipe Inside Diameter	5 X Pipe Inside Diameter
90° Elbow	20 X Pipe Inside Diameter	5 X Pipe Inside Diameter
Two 90° Elbows -1 Direction	25 X Pipe Inside Diameter	5 X Pipe Inside Diameter
Two 90° Elbows -2 Directions	40 X Pipe Inside Diameter	5 X Pipe Inside Diameter
Pump Or Gate Valves	50 X Pipe Inside Diameter	5 X Pipe Inside Diameter

Mounting location and pressure/temperature requirements

- The meter is designed to withstand outdoor conditions. A cool, dry location, where the unit can be easily serviced is recommended.
- The meter can be mounted on horizontal or vertical runs of pipe. Mounting at the vertical (twelve o'clock) position on horizontal pipe is recommended. Mounting anywhere around the diameter of vertical pipe is acceptable, however, the pipe must be completely full of water at all times. Back pressure is essential on downward flows. See the minimum straight length of pipe requirement chart above.
- The meter can accurately measure flow from either direction.



5300 Business Drive, Huntington Beach, CA 92649 ● (ph) 714-893-8529 ● (fx) 714-894-9492 ● (em) sales@blue-white.com

View Technical Data at www.blue-white.com

