H.B. Abrams Company

218 No. Woods Ave, Fullerton, Calif., 92832 Tel: (714)526-6696 Fax: (714) 526-6616 www.hbabrams.com



025A SINGLE STAGE WIND CONTROLLER

Description

Provides one adjustable setpoint and one spdt output relay that trips instantly on setpoint. The relay output resets 60 seconds after the wind speed remains continuously below the setpoint.

This model can control the display pump circuit on simple fountains, prevent irrigation systems from operating in high wind conditions, and activate the high wind alarm in crane applications. An optional large remote wind speed display is available.


The wind speed is measured by means of an H.B. Abrams Company model 041 cup anemometer. The anemometer is constructed with lightweight, UV resistant plastic. The anemometer mount is a ½" npt brass conduit connection. Refer to the model 041 datasheet for more detail.

The model 025A is standard with analog wind speed indication meter, calibrated for 0 to 30 mph display, 120vac single phase power input, and 5 amp relay output. Included is one cup anemometer sensor, but can accept input from two. The relay stage features an off delay of 60 seconds to prevent excessive starting of the display pump.


Installation


The controller enclosure is moisture proof but intended to be mounted indoors or under a cover to protect it from direct rain and sunlight. The anemometer (sensing head) can be mounted up to 500' away, with its own conduit and suitable cable (Belden 9250 or similar). The anemometer should be mounted upwind of the fountain by at least 50'. This allows the controller to adjust or shut down the display before the wind gust gets to the fountain.

Dimensional Drawing




Connection Diagram








Suggested Electrical Connection





Specifications

Operational range0-30 mph
Accuracy5% of full scale
Set point adjustable range0 mph to 30 mph
Relay off delay60 seconds
Enclosure typeNEMA 4 painted steel
Enclosure dimensions
Input voltage120 vac nominal
Input frequency50/60 Hz
Power consumption5 watts
Shipping weight
Temperature range32°f to 140°f

Anemometer cable22ga twisted pair or better (cat5 ok)
Operator controls: Setpoint set switch Setpoint knob
System test switch Operator indicators: Power Wind speed / setpoint adjust meter Setpoint "tripped"
Digital output5 amp SPDP relay contact
WarrantyOne year